



SEGWAY TECHNOLOGY CO., LTD.
powersports.segway.com

Vision 20230928
A10-L200003-LEN-00



OWNER'S MANUAL

SGW500F-A7 SGW500F-A8

WELCOME

Thank you for buying this vehicle Segway. Segway off-road vehicles will bring you a new driving experience.

For your driving safety, you must read this manual before riding. This manual contains a large number of safety instructions, operation instructions, maintenance instructions and safety warnings.

A careful reading of this manual will help you to quickly understand the vehicle and your full driving to help.

Periodic maintenance procedures are included in this manual and are performed regularly to assist in your vehicle safety.

WARNING

Read, understand, and follow all of the instructions and safety precautions in this manual and all product labels.

Failure to follow the safety precautions could result in serious injury or death.

IMPORTANT NOTICE

This vehicle is designed and manufactured for on-road use and complies with all applicable on-road noise, vibration and emission regulations.

Before driving the vehicle, please understand the local laws and regulations, choose the allowed road driving, abide by the local traffic regulations.

This manual is applicable to the ATV fuel series and describes all equipment including optional components. Therefore, some of the optional equipment described in the manual may be not installed on your vehicle.

All specifications provided in this manual are up to date at the time of printing. However, due to continuous product improvement, the contents of this manual will be updated at any time without prior notice. The descriptions and/or procedures in this publication are for informational purposes only. Take no responsibility for omissions or inaccuracies. Express prohibition or reuse of descriptions and/or programs contained in whole or in part.

If your vehicle needs any service and repair matters, please contact our dealer, our dealer will provide satisfactory service in a timely manner.

Login on <http://powersports.segway.com> query the nearest Segway dealer or service locations.



TABLE OF CONTENTS

SAFETY INTRODUCTION	1
VEHICLE DEVICE	24
OPERATION	58
MAINTENANCE, STORAGE AND TRANSPORTATION	82
SPECIFICATIONS	144
TROUBLESHOOTING	151
EMISSION CONTROL SYSTEM	162
WARRANTY	168

INTRODUCTION BEFORE YOU RIDE

This SEGWAY vehicle is an on-road vehicle. Familiarize yourself with all laws and regulations concerning the operation of this vehicle in your area.

WARNING

- Failure to heed the warnings and safety precautions contained in this manual can result in severe injury or death. Your SEGWAY vehicle is not a toy and can be hazardous to operate. This vehicle handles differently than cars, trucks or other on-road vehicles. A collision or rollover can occur quickly, even during routine maneuvers like turning, or driving on hills or over obstacles, if you fail to take proper precautions.
- Read this owner's manual that came with your vehicle. Understand all safety warnings, precautions and operating procedures before operating the vehicle. Keep this manual with the vehicle.
- Never operate this vehicle without proper instruction. Take an authorized training course. See the Safety Training section for more information.
- This vehicle is an ADULT VEHICLE ONLY. You MUST be at least age 16 and have a valid driver's license to operate this vehicle.
- Always use the cab nets (or doors) while riding in this vehicle. Always keep hands, feet and all other body parts inside the vehicle at all times.

- Always wear a helmet, eye protection, gloves, long-sleeve shirt, long pants and over-the-ankle boots.
- Never operate this vehicle under the influence of drugs or alcohol, as these conditions impair judgement and reduce the operator's ability to react.
- Complete the New Operator Driving Procedures outlined this manual Never allow a guest to operate this vehicle until the guest has completed the New Operator Driving Procedures.
- Never permit a guest to operate this vehicle unless the guest has reviewed the owner's manual and all safety labels and has completed a safety training.

The meaning of these signs



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

DANGER

DANGER indicates a hazardous situation which, if not avoided, will result in death or serious injury.

WARNING

WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.

CAUTION

CAUTION, used with the safety alert symbol, indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

CAUTION

CAUTION, used without the safety alert symbol, is used to address practices not related to personal injury.

NOTICE

NOTICE is used to address practices not related to personal injury.

The Prohibition Safety Sign indicates an action **NOT** to take in order to avoid a hazard.



The Mandatory Action Sign indicates an action that **NEEDS** to be taken to avoid a hazard.







SAFETY INTRODUCTION



WARNING LABELS	3
SPECIAL SAFETY MESSAGES	8
IMPORTANT SAFETY INFORMATION	11
READING THE MANUAL.....	11
SAFE DRIVING AGE	12
USING ALCOHOL OR DRUGS	13
RIDING EQUIPMENT.....	14
VEHICLE MODIFICATION.....	16
PASSENGERS	17
CONTACT EXHAUST.....	18
UNAUTHORIZED USE OF THE VEHICLE.....	19
FUEL SAFETY.....	19
FAILURE TO INSPECT BEFORE OPERATING.....	20
IMPROPER TIRE MAINTENANCE.....	20
OPERATING ON FROZEN BODIES OF WATER.....	21
OPERATING AT EXCESSIVE SPEEDS.....	21
HOT EXHAUST SYSTEMS.....	22
OPERATING A DAMAGED VEHICLE	22
SKIDDING AND SLIDING	22
OPERATING IN UNFAMILIAR TERRAIN	23
IMPROPER HILL CLIMBING.....	23
DESCENDING HILLS IMPROPERLY.....	23

Failure to follow the warnings and safety precautions in this manual may result in serious injury or death. It can be dangerous to operate an ATV that is not regulated and is driven differently from other vehicles, such as motorcycles and automobiles. If proper precautions are not taken, a collision or rolled-over may occur during normal maneuvers such as turning, climbing, or overcoming obstacles. Understand all safety warnings, precautions and operating procedures before operating the vehicle. Bring this manual with you.

WARNING LABELS

Warning labels have been placed on the vehicle for your protection. Read and follow the instructions on the labels carefully. If any of the labels depicted in this manual differ from the labels on your vehicle, always read and follow the instructions on the vehicle. If any label becomes illegible or comes off, contact Segway Powersports to obtain a replacement.





1

⚠ WARNING

Improper ATV use can result in SEVERE INJURY or DEATH.



ALWAYS USE
AN APPROVED
HELMET AND
PROTECTIVE
GEAR



NEVER CARRY
MORE THAN
1 PASSENGER



NEVER USE
WITH DRUGS
OR ALCOHOL

NEVER operate:

- Without proper training or instruction.
- At speeds too fast for your skills or the conditions.
- On public roads—a collision can occur with another vehicle.

ALWAYS:

- Use proper riding techniques to avoid vehicle overturns on hills and rough terrain and in turns.
- Avoid paved surfaces—pavement may seriously affect handling and control.

LOCATE AND READ OWNER'S MANUAL.
FOLLOW ALL INSTRUCTIONS AND WARNINGS

2

⚠ WARNING

Passengers under 12 are prohibited.
Passenger should be well seated & hold tight the handgrip during public road operation.



Passenger seat could be used during public roads operation.
Passenger seat shall not be used during field operation.

3

⚠ WARNING

Operating this ATV if you are under the age of 16 increases your chances of severe injury or death to both operator and passenger.

NEVER operate this vehicle if you are under age 16.

4

⚠ WARNING

• **DO NOT TOW FROM RACK OR BUMPER.**
Vehicle damage or tipover may result in severe injury or death. Tow only from tow hooks or hitch.

• **Max Rack Loads: Front 88 lbs (40kg)
Rear 132lbs (60kg)**

5

⚠ WARNING

- Step on the brake pedal each time the gear is changed.
- When the ATV is unmanned, the transmission must be placed in parking gear.

6

⚠ WARNING

Turning the vehicle in 4WD-LOCK ("DIFF. LOCK") takes more efforts. Operate at a slow speed and allow extra time and distance for maneuvers to avoid loss of control.

7



Unleaded fuel only

8

⚠ WARNING

Improper tire pressure or overloading can cause loss of control. Loss of control can result in severe injury or death.

- Cold tire pressure:
Front: 7.0psi (48.3kPa)
Rear: 7.0psi (48.3kPa)

9



10

CAUTION

The air filter must be maintained in accordance with the requirements of the Segway Owner's Manual, otherwise it may seriously damage your engine.

11

⚠ WARNING

Improperly loading a trailer may cause loss of control. Evenly balance the load.

- Maximum unbraked towing mass 150 kg (331 lb)
- Maximum unbraked tongue mass 100 kg (220 lb)
- Maximum inertibraked towing mass 600 kg (1323 lb)
- Maximum inertibraked tongue mass 100 kg (220 lb)

A10-L100056-LEN-00

SPECIAL SAFETY MESSAGES

SEVERE INJURY OR DEATH can result if you do not follow these instructions:

- The minimum recommended driving age for this vehicle is 16 years.
- Never operate this vehicle without wearing an approved motorcycle helmet that fits properly. You should also wear eye protection (goggles or a face shield), gloves, over-the-ankle boots, long-sleeved shirt or jacket and long pants.
- Never consume alcohol or drugs before or while operating this vehicle.
- Never attempt jumps of stunts.
- Never operate at speeds too fast for your skills or the conditions. Always go at a speed that is proper for the terrain, visibility, operating conditions and your experience.
- Always inspect your vehicle each time you use it to be sure it is in safe operating condition.
- Never operate on excessively rough, slippery or loose terrain until you have learned and practiced the skills necessary to control the vehicle on such terrain. Always be especially cautious on these kinds of terrain.
- Always follow the inspection and maintenance procedures and schedules described in this manual.
- Never operate on hills that are slippery or ones where you will not be able to see far enough ahead of you.
- Never go over the top of a hill at speed if you cannot see what is on other side.
- Always keep both hands on the handlebars when driving.

- Always go slowly and be extra careful when operating on unfamiliar terrain. Always be alert to changing terrain conditions when driving the vehicle.
- Never turn at excessive speed. Practice turning at slow speeds before attempting to turn at faster speeds. Do not attempt turns on steep inclines.
- Always follow proper procedures for going uphill. If you lose control and cannot continue up a hill, back down the hill with the engine in reverse gear. Use engine braking to help you go slowly. If necessary, use the brakes gradually to help you go slowly.
- Never operate the vehicle on hills that are too steep for it or for your abilities. Go straight up and down hills where possible.
- Never operate the vehicle in fast flowing water or water deeper than the floorboards on this model. Remember that wet brakes may reduce stopping ability. Test your brakes after leaving water. If necessary, apply the brake several times to let friction dry out the linings.
- Always be sure there are no obstacles or people behind you when you operate in reverse. When it is safe to proceed in reverse, go slowly.
- Always check terrain before going down hills. Go as slowly as possible. Never go down a hill at high speed.
- Always check for obstacles before operating in a new area.
- Do not brake abruptly when carrying loads.
- Always use the size and type of tires specified in this manual.
- Always maintain proper tire pressure as described in this manual.
- Never exceed the stated load capacity. Cargo should be

distributed evenly between the front and rear racks. Be sure cargo is secured so that it cannot move around during operation. Reduce speed and follow instructions in this manual for carrying cargo or pulling a trailer. Allow greater distance for braking.

- Brake discs can be over-heated after continuous braking. Allow brake disc to cool before servicing.
- Be aware of burn and fire risks related to contact with hot surfaces, including residual risks such as filling of oil or coolant, hot engines or transmissions.
- Exhaust system components are very hot during and after use of the vehicle. Hot components can cause burns and fire. Do not touch hot exhaust system components. Always keep combustible materials away from the exhaust system.
- Use caution when traveling through tall grass, especially dry grass. Always inspect the underside of the vehicle and areas near the exhaust system after driving through tall grass, weeds, brush, and other tall ground cover. Promptly remove any grass or debris clinging to the vehicle.

IMPORTANT SAFETY INFORMATION

READING THE MANUAL

WARNING

Driving an ATV improperly increases the risk of accidents. The driver must know how to drive the vehicle correctly in different situations and on different terrains.

Before driving the vehicle, all drivers must complete the required driving safety training. Please ensure that each driver has read this manual and all product warning labels and has passed the safety training course.



SAFE DRIVING AGE

WARNING

The minimum recommended driving age for this vehicle is 16 years. Children under the age of 16 must not drive this vehicle. Training courses are required. Please ensure that each driver has read this manual and all product labels as well as has completed a safety training course.



USING ALCOHOL OR DRUGS

WARNING

Operating this vehicle after consuming alcohol or drugs could adversely affect operator judgment, reaction time, balance and perception.

Never consume alcohol or drugs before or while operating this vehicle.



RIDING EQUIPMENT

WARNING

For your safety, we strongly recommend that you always wear an approved motorcycle, eye protection, boots, gloves, long pants, and a long-sleeved shirt or jacket whenever you ride.

Although complete protection is not possible, wearing proper gear can reduce the chance of injury when you ride.

Helmet

Wearing a helmet can prevent head injuries. At all times, you must wear a helmet that meets basic safety standards when driving. Both U. S. and Canadian qualified helmets bear a U. S. Department of Transportation label. ECE 22.05 marks are available in Europe, Asia and Oceania. The ECE mark consists of a circle around the letter E, followed by the approved area codes for different countries. The approval number and serial number are also displayed in the label.

Additional Riding Gear


Sturdy off-road motorcycle boots to help protect your feet, ankles, and lower legs.

On-road motorcycle gloves to help protect your hands.

Riding pants with knee and hip pads, a riding jersey with padded elbows, and a chest/ shoulder protector.

⚠ WARNING

Driving ATV after drinking or taking drugs may adversely affect a driver's judgment, reaction time, balance, and feelings. Do not drink alcohol or take drugs before or during driving.



VEHICLE MODIFICATION

WARNING

We strongly recommend that consumers do not attempt to increase vehicle speed or use any equipment that increases the power of the vehicle. If any equipment is added to the vehicle, or if any modifications are made to the vehicle to increase the vehicle speed or power, the all-terrain vehicle warranty is terminated. The addition of certain parts may change the handling of the vehicle, including (but not limited to) mowers, sledges, tires, sprayers, or large luggage racks.



PASSENGERS**⚠ WARNING**

Passengers severely reduces a driver's ability to balance and control ATVs, which can lead to accidents or rollovers. Never exceed the number of passengers allowed by the vehicle.

Maximum passenger: 1 person



CONTACT EXHAUST

WARNING

Engine exhaust is toxic and can cause loss of consciousness or death in a short time. Do not start or run a motor in a closed space. The engine exhaust of this product contains chemicals that cause cancer, birth defects or other reproductive damage, and you can only drive it outside or in a well-ventilated place.



UNAUTHORIZED USE OF THE VEHICLE

WARNING

If the key is left in the ignition, those people under the age of 16 or without a license, or without proper training can use the vehicle illegally. This could cause an accident or a rollover. Always remove the ignition key when the vehicle is not in use.

FUEL SAFETY

WARNING

Gasoline is very flammable under certain conditions.

- You must be extremely careful when dealing with gasoline.
- When refueling, the engine must be shut off and must be done outdoors or in a well-ventilated area.
- At or near the refueling or gasoline storage place. No smoking, no open flames or sparks.
- Do not overflow when refueling. Do not fill the tank to the neck.
- If gasoline gets on your skin or clothes, wash them with soap and water immediately and change clothes.

FAILURE TO INSPECT BEFORE OPERATING** WARNING**

- Failure to inspect and verify that the vehicle is in safe operating condition before operating increases the risk of an accident and .
- Always perform the pre-ride inspection before each use of your vehicle to make sure it's in safe operating condition.
- Always follow the inspection and maintenance procedures and schedules described in this owner's manual.

IMPROPER TIRE MAINTENANCE** WARNING**

- Operation this vehicle with improper tires or with improper or uneven tire pressure could cause loss of control or an accident.
- Always use the size and type of tires specified for your vehicle.
- Always maintain proper tire pressure as described in the owner's manual and on safety labels.

OPERATING ON FROZEN BODIES OF WATER

WARNING

- Severe injury or death can result if the vehicle and/or the operator fall through the ice. Never operate the vehicle on a frozen body of water unless you have first verified that the ice is sufficiently thick to support the weight and moving force of the vehicle, you and your cargo, together with any other vehicles in your party.
- Always check with local authorities and residents to confirm ice conditions and thickness over your entire route. Vehicle operators assume all risk associated with ice conditions on frozen bodies of water.

OPERATING AT EXCESSIVE SPEEDS

WARNING

- Operating this vehicle at excessive speeds increases the operator's risk of losing control.
- Always operate at a speed that's appropriate for the terrain, visibility and operating conditions and your skills and experience.

HOT EXHAUST SYSTEMS

WARNING

- Exhaust system components are very hot during and after use of the vehicle. Hot components can cause burns and fire. Do not touch hot exhaust system components. Always keep combustible materials away from the exhaust system.
- Use caution when traveling through tall grass, especially dry grass. Always inspect the underside of the vehicle and areas near the exhaust system after driving through tall grass, weeds, brush, and other tall ground cover. Promptly remove any grass or debris clinging to the vehicle.

OPERATING A DAMAGED VEHICLE

WARNING

Operating a damaged vehicle can result in an accident. After any rollover or other accident, have a qualified service dealer inspect the entire machine for possible damage, including but not limited to seat belts, rollover protection devices, brakes, throttle and steering systems.

SKIDDING AND SLIDING

WARNING

Failure to use extra caution when operating on excessively rough, slippery or loose terrain could cause loss of traction, loss of control, accident or rollover. Do not operate on excessively slippery surfaces. Always slow down and use additional caution when operating on slippery surfaces.

OPERATING IN UNFAMILIAR TERRAIN

WARNING

- Failure to use extra caution when operating on unfamiliar terrain could result in an accident or rollover.
- Unfamiliar terrain may contain hidden rocks, bumps, or holes that could cause loss of control or rollover.
- Travel slowly and use extra caution when operating on unfamiliar terrain. Always be alert to changing terrain conditions.

IMPROPER HILL CLIMBING

WARNING

Improper hill climbing could cause loss of control or rollover. Use extreme caution when operating on hills. Always follow proper procedures for hill climbing as described in this owner's manual. See the New Operator Driving Procedures section for details.

DESCENDING HILLS IMPROPERLY

WARNING

Improperly descending a hill could cause loss of control or rollover. Always follow proper procedures for traveling down hills as described in this owner's manual.

VEHICLE DEVICE

VEHICLE ACTIVATION	26
UNLOCK VEHICLE	27
APP FUNCTION	27
CONTROLS	28
IGNITION LOCK	29
LEFT HANDLE SWITCH	30
WINCH SWITCH (IF EQUIPPED).....	32
TWO OR FOUR WHEEL DRIVE SWITCHING SWITCH	33
ACCELERATOR	35
INSTRUMENT PARTS	36
INSTRUMENT INDICATOR LIGHT/WARNING LIGHT	37
INSTRUMENT INFORMATION DISPLAY AREA	39
SCREEN FUNCTION SETTING	42
DIAGNOSTIC DISPLAYS CODE DEFINITIONS.....	43
GEAR SHIFTER OPERATION	44
MAIN BRAKE.....	45
AUXILIARY BRAKE.....	45
PARKING BRAKE	46
PARKING BRAKE LEVER FREE CLEARANCE	47
FOOT BRAKE LEVER ADJUSTMENT	48
EQUIPMENT COMPONENT	49
STANDBY POWER OUTPUT SEAT	50
FUEL TANK CAP	51
CUSHION.....	52
CUSHION INSTALLATION	52
BACKREST (2-UP)	53



VEHICLE DEVICE

DRIVER'S TOOL SET	53
PASSENGER HANDRAILS	54
FOOT PEDALS	54
STORAGE BOX	55
RACKS	56
HANDLEBAR ADJUSTMENT	57

VEHICLE ACTIVATION

This vehicle is equipped with vehicle T-BOX system for you. T-BOX is used to communicate with background system and mobile APP, so as to obtain vehicle information and control the vehicle with mobile APP. This is an optional system. In order to make you quickly familiar with and use the system, please read the user's manual carefully, understand the relevant operation and use information.

NOTICE

The new vehicle must be activated on the APP for the first time if equipped with vehicle T-BOX, otherwise the engine will not start.

Please download the APP from the “Apple® App Store®” or “Google Play® store” in your mobile phone before you try to activate the Vehicle by the APP in the first time. Please search “**Segway powersports**” in the “Apple® App Store®” or “Google Play® store” in your mobile phone then download the APP as usual.

After the successful installation of the APP, the vehicle will be registered and activated. First, find the VIN code on the vehicle and register on the APP. The registration procedure is as follows:

1. Power on the vehicle with the mechanical key.

Input or scan vehicle VIN code according to APP registration prompts, and step on the vehicle brake at the same time. The VIN barcode is located under the seat cushion. Note: The vehicle identification code may not be scanned due to the influence of light. You can try to enter the VIN code manually. The vehicle VIN code is either on the vehicle frame (see Page 149) or on the vehicle nameplate (see Page 150).

2. Click the “**CONFIRM**” button to complete the vehicle binding operation.

3. Click “**START**” to start the vehicle.

UNLOCK VEHICLE

There are three ways to unlock a vehicle:

1. **Mechanical key (preferred).**
2. **APP remote unlock vehicle**

APP Remote Unlock is based on 4G network. As long as the area is covered by the network, you can use the remote unlock function in the APP to power the vehicle.

3. **APP Bluetooth unlock vehicle**

When both the vehicle and the mobile phone are on, within the effective connection distance of the Bluetooth signal, the vehicle Bluetooth module will automatically unlock the vehicle after acquiring the mobile phone Bluetooth signal, and automatically lock the vehicle when the mobile phone is far away.

NOTICE

After using the mechanical key to power down, the vehicle cannot be unlocked by induction to power up again. It needs to disconnect the reconnection and close the unlock to restart.


Mechanical key unlock is the optimal unlock method for vehicles. If you do not want to use the sensor unlock function, the sensor unlock setting can be turned off in the APP.

APP FUNCTION

This app is a program designed for users who have the Segway vehicle.

Main features: driving control analysis, vehicle data analysis, etc.

CONTROLS



1 Ignition Switch

2 Left handle Switch

3 Accelerator

4 2/4 WD Switch


5 Instrument

6 Shift Level

7 Brake/Parking Lever

8 Brake Pedal

IGNITION LOCK



“ON”: Power On

“OFF”: Power Off

“LOCK”: Steering Lock

The ignition lock is located in the central zone of the handlebars.


Turn the key to position “ LOCK ”: Lock the rotation direction of the vehicle, so that the vehicle direction is in a fixed position.

Turn the key to position “ ON ” : Vehicle is powered on, the vehicle’s electrical components can be used.

Turn the key to position “ OFF ” : Vehicle is powered off, when the switch is in the off position, the key can be removed from the switch.

Turn the key to the START position to engage the electric starter. See the starting the engine section for starting procedures.

LEFT HANDLE SWITCH



1 Engine start/stop switch

“⤵” : Engine power on “⊗” : Engine stop “⚡” : Engine start

Start the engine

1. Turn the ignition key to the "ON" position.
2. Tighten the foot brake.
3. Press the engine start-stop switch to the "⚡" position and release it, the engine will start, and the switch will automatically return to the "⤵" position.

Stop engine

Press the engine start-stop switch to the "⊗" position, the engine stops.

2 Headlight switch

This switch is located in the light switch. The corresponding position corresponds to different light modes.

High beam mode "⤵": Turn on the vehicle high beam mode and the "⤵" sign on the instrument will be lit.

Low beam mode "⤵": Turn on the vehicle near-light in the mode of near-light.

"OFF": Light off mode

When the ignition lock is in the "ON" position, push the switch to the desired mode position, and to turn OFF the light, push the switch to the " OFF "position.

3 Left right steering switch

← Switch Slide to the left, left turn signal on. At this point, the " ← " chart of the meter is brightly punctuated.

→ Switch slides to the right, right turn signal on. At this point, the " → " chart of the meter is brightly punctuated.

- Turn off the turn signal in the middle position.


4 Horn Switch "  "**5 "  " Emergency switch**

Use this switch in case of emergency, press the switch to start, and press stop again.The vehicle position light flashes when the emergency switch is on.

- Temporary parking of vehicles.
- Failure of the vehicle.
- When the vehicle encounters other emergencies.

6 Force-multiplier switch

Increase the maximum speed limit of the vehicle in 4WD lock mode (speed limit 30KM/h). When the vehicle on 4WD locked (instrument shows 4WD locked symbol "  "), the vehicle speed limit to 30km/h, at this time, if the vehicle has insufficient power because of terrible road conditions, you can keep holding press this switch, the vehicle will lift the speed limit and enhance the power, it maybe help you out of trouble.


WINCH SWITCH (IF EQUIPPED)

OUT: Release the winch wire rope

IN: Retract the winch rope

The winch is used to drag the load, understand the correct use of the winch steps and methods, pay attention to the use of safety matters, for the use of the winch instructions and precautions, please refer to the relevant chapters.

TWO OR FOUR WHEEL DRIVE SWITCHING SWITCH



1 Drive mode selection handle

2 Front axle differential lock button

3 Two-wheel drive position

4 Four-wheel drive position

5 Rear axle differential lock button

NOTICE


The vehicle must be stopped to engage or disengage 2WD/4WD switch. Mechanical damage may occur if switch is engaged or disengaged while driving.

Button operation	Instrument indicator light	Model	Mode Status Description
Rear axle differential mode			
Rotate the selection handle to the "  " position Rear axle differential lock button "  " press		2x4 two-wheel drive mode	At this time, the two-wheel drive mode is turned on, and the whole vehicle is only driven by the rear wheels, and the front wheels have no power output. This mode is suitable for driving on smooth roads.

<p>Rotate the selection handle to the "  " position</p> <p>Rear axle differential lock button "  " press</p>		<p>4x4 four-wheel drive mode</p>	<p>At this time, the four-wheel drive mode is turned on, the front wheels have power output, and the rear wheels have power output. This mode is suitable for bad road conditions such as muddy and mountainous areas.</p>
<p>Front axle differential lock button "  " pops up</p> <p>Rear axle differential lock button "  " press</p>		<p>4x4 lock mode</p>	<p>At this time, the vehicle is working in 4WD lock state, the front wheels have power output, the rear wheels have power output, the front wheels of the left and right tires output the same speed and power. Vehicle in 4WD locking state will be in a speed-limited state, the vehicle speed does not exceed 30km/h, this mode is suitable for the vehicle to get out of trouble.</p>
<p>Rear axle lock mode</p>			
<p>Rotate the selection handle to the "  " position</p> <p>Rear axle differential lock button "  " pops up</p>		<p>2x4 two-wheel drive mode</p>	<p>At this time, the two-wheel drive mode is turned on, and the whole vehicle is only driven by the rear wheels, and the front wheels have no power output. This mode is suitable for driving on smooth roads.</p>
<p>Rotate the selection handle to the "  " position</p> <p>Rear axle differential lock button "  " pops up</p>		<p>4x4 four-wheel drive mode</p>	<p>At this time, the four-wheel drive mode is turned on, the front wheels have power output, and the rear wheels have power output. This mode is suitable for bad road conditions such as muddy and mountainous areas.</p>
<p>Front axle differential lock button "  " pops up</p> <p>Rear axle differential lock button "  " pops up</p>		<p>4x4 rear axle lock mode</p>	<p>At this time, it works in the 4-wheel drive locked state, the front wheels have power output, the rear wheels have power output, and the tires on the left and right sides of the front and rear wheels output the same speed and power. the vehicle will be in the speed limit state when the 4-wheel drive is locked, and the speed does not exceed 30km/h. This mode is suitable for the vehicle to get out of trouble.</p>

ACCELERATOR

The throttle controls the engine speed, to increase the engine speed, press the throttle lever with your thumb, to reduce the engine speed, release the pressure of the throttle lever, and when you release your thumb, the engine returns to idle.



Accelerator

WARNING

Before driving, check whether the throttle is normal. If the throttle is stuck or the throttle is not operating properly, it will cause an accident. Do not start or drive the vehicle when the throttle is stuck or the throttle is not operating properly.

INSTRUMENT PARTS


The instrument provides the operator with the vehicle running parameter information, and the driver should understand the meaning of various indicators, warning lights and display content information on the instrument display, so as to timely understand the vehicle status.

NOTICE

The combination instrument may be damaged by using a high pressure cleaner. Do not clean the instrument with alcohol or corrosive detergent. Corrosive liquid will corrode the surface of the instrument and cause damage to the instrument.

INSTRUMENT INDICATOR LIGHT/WARNING LIGHT

Indicator lights and warning lights on the instrument indicate the status of the vehicle's systems. The figure below shows all the lights and warning lights to illustrate.




Indicator light/warning indication

Item	Legend	Functional specifications
Left Turn Signal		This light is lit when the left turn signal is turned on.
High Beam		This lamp illuminates when the headlamp switch is set to high beam.
Driving Lights		The front light, tail light, license plate light and instrument panel light are on.
Check Engine		This indicator appears if an EFI-related fault occurs. Do not operate the vehicle if this warning appears. Serious engine damage could result.

Oil Pressure Warning		This light is on when oil pressure is too low.
Fuel level		The lamp lights up when the fuel level is too low.
Warning for leave	OPC	This light is on after leaving the seat and the buzzer will beep when OPC is on.
Right Turn Signal		This light is lit when the right turn signal is turned on.
Neutral	N	This light is on when the gear shifter is in neutral (green).
Parking		This light is on after parking brake is applied.
Brake warning light		<ul style="list-style-type: none"> • Low brake fluid level • The braking system is faulty
Electric steering warning light		Indicates a failure in EPS system (optional equipment, if equipped).
Coolant temperature warning lamp		Indicator light showing excessive temperature of engine coolant. When it lights up and alarms, the engine should be stopped immediately and shut down. After cooling down to normal temperature, the engine should continue to run.

INSTRUMENT INFORMATION DISPLAY AREA




No	Graphic Meaning	Functional specifications
1	Time	Display current time
2	Bluetooth	When mobile Bluetooth and T-BOX are connected successfully and the light will be on.
3	Remote access to electricity	When power on the ATV, the APP in the mobile phone, Click the "remote power on" button and the light will be on. (The premise is that T-BOX networking is successful)
4	Logo	This sign lights up after power on.
5	Speed	Display the actual vehicle speed The speedometer shows a speed of MPH (mile) or km/h (km/h).

6	Gear display	<p>Display the correct gear</p> <p>L -Low speed</p> <p>H -High speed</p> <p>R -Reverse</p> <p>P -Parking</p>
7	Engine speed	Display actual engine speed
8	Four-wheel drive full differential lock	 2 x 4 patterns  4 x 4 patterns  4x4 locking mode
9	Coolant temperature indicator	<p>Display current coolant temperature</p> <p>H -High temperature</p> <p>C -Low temperature</p>
10	Battery Voltage	Display the current voltage of the vehicle battery
11	Subtotal mileage	Single trip mileage
12	Fault code display	When ECU、EPS、T-BOX fails, the fault code is displayed in this area. See page 159 for detailed description of the fault code.

13	Engine running time	Display engine running time
14	Total mileage	Display the total mileage accumulated by the vehicle
15	EPS On (Only brushless EPS is supported)	M -Normal mode, power normal H -Comfort mode, power light L -Motion mode, booster weight
16	Fuel meter	Display the current amount of fuel F -High fuel volume E -Fuel volume low

SCREEN FUNCTION SETTING




1 Left button

2 Right button

Function	Left button	Rihtt button	Display
Brightness adjustment	Short press		Adjust backlight brightness (default: brightest)
Subtotal Clear	Long press		Zero subtotal mileage
EPS gear switching		Short press	EPS level shift signal sent
Metric or imperial units		Long press	Metric or imperial units switching
Clock settings	Long press	Long press	Clock hour flashing
	Short press		Hour+1
		Long press	Hour continuous+1
	Short press		Clock minute flashing
		Short press	Minute+1
		Long press	Minute continuous +1

DIAGNOSTIC DISPLAYS CODE DEFINITIONS

This area displays the code information when the vehicle electrical components, wiring and other malfunctions or abnormalities, through the code to understand the corresponding abnormalities, so as to seek ways to solve the problem, the code interpretation is detailed in the "Diagnostic displays code definitions", see page 159.



1 Fault code display area

GEAR SHIFTER OPERATION

Different operation modes correspond to different gears. After selecting the gear, check the indicator light on the instrument panel to ensure that the gear has been switched to the desired position. See the table below for the tap position description:




- L** Low speed
- H** High speed
- N** Neutral
- R** Reverse
- P** Parking

NOTICE

You need to step on the brake pedal when you change the gear.


If you change the gear when the engine is in idle speed or the vehicle is moving, it can cause transmission damage. Please place the transmission in parking gear and lock the parking brake when nobody drives the ATV.

MAIN BRAKE



The foot brake is the main brake system of the vehicle. The main brake is located on the right foot plate of the vehicle. When the vehicle needs to slow down or stop, step on the foot brake slowly. Emergency braking can cause the vehicle to skid or roll over, so do not use emergency braking when it is not necessary.

AUXILIARY BRAKE



Auxiliary braking system refers to the backup device used as the main braking system. If the main brake system fails, use the auxiliary foot brake.

The auxiliary brakes are located on your right handle. use the auxiliary


brakes to brake the front wheels of the vehicle. If the rear wheels slide while using the auxiliary brakes, the brake lever pressure is reduced to prevent the rear wheels from slipping while braking.

⚠ WARNING

Use the auxiliary brake with caution when riding downhill, the use of the auxiliary brake may result in a sideslip dump or sideways rollover, which could result in serious injury or death.

PARKING BRAKE

The parking brake on the left handlebar side.



- 1 Parking brake lever** **2 Parking brake lock**

Using the parking brake:


Place the shifter in "P" and squeeze the parking brake lever and hold. Squeeze the parking brake lever and hold it, rotate the parking brake lock upward, parking is completed when you hear a "click".

Release the parking brake lever:

Squeeze the parking brake lever, parking brake is released when you hear a "click".


PARKING BRAKE LEVER FREE CLEARANCE

Brake lever brake empty travel



1. Squeeze the parking brake lever with force, squeeze and release the action, repeat a few times, the parking brake lever shall not be stuck.
2. Measure the distance the parking brake lever moves before the brake starts to hold. Free travel (measure the tip of the end of the brake lever) Ⓐ should be: (25-30mm)
3. As the brake pads wear, the travel of the brake handle will increase. Therefore, brake pads need to be checked for wear from time to time and must be replaced when the wear limit is reached.


FOOT BRAKE LEVER ADJUSTMENT



The foot brake lever adjusting nut is located at the bottom of the vehicle near the foot brake lever. The stroke height of the foot brake lever can be adjusted by twisting the foot brake lever nut.

- Turn the nut clockwise, foot brake lever down.
- Turn the nut counterclockwise, foot brake lever up.

EQUIPMENT COMPONENT



- | | |
|------------------------------------|-------------------------------|
| 1 Standby power output seat | 2 Fuel filler spout |
| 3 Cushion | 4 Backrest (2-UP) |
| 5 Passenger handrails | 6 Foot pedals |
| 7 Storage box | 8 Front and rear racks |
| 9 Steering handlebar | |

STANDBY POWER OUTPUT SEAT

Power sockets are available for 12V accessories with operating current less than 10A.

The vehicle is equipped with two 12V DC ports.

Output power: 12V

USB port and DC port



Open the lid

Service conditions of power sockets:


Place the ignition key in " ON " mode.

FUEL TANK CAP

WARNING

Always fill the fuel type specified by the vehicle. Do not smoke when filling the fuel or it may ignite the fuel and cause a fire disaster.

Do not touch other persons or objects with static electricity, which may cause static electricity and ignite the fuel. Do not overfill the fuel.




1. Unscrew the fuel cap clockwise.
2. Refuel the vehicle (don't overfill it).
3. Tighten the fuel tank cap .

CUSHION

Cushion removal

The cushion is a snap-on quick release part.

1. Hook the cushion hook with your fingers and move it upward.
2. Lift the cushion upward after it springs open.
3. Remove the cushion.



NOTICE

There is a cable connection under the cushion, please be careful when removing the cushion and moving it upwards.

CUSHION INSTALLATION

Insert the lug on the front of the cushion into the center of the U-bracket welded to the frame, push the cushion forward firmly and press the cushion down to lock it.

⚠ CAUTION

After the cushion is installed, double-check that the installation is secure.

BACKREST (2-UP)

Backrest removal

The backrest can be removed after the three bolts and nuts fixing the backrest are removed in turn.



Backrest installation


Place the backrest mounting holes into the corresponding mounting holes of the backrest mounting bracket and fasten with 3 hexagonal flange bolts M8×16 and M8 nuts.

DRIVER'S TOOL SET

The driver's tool set is located in the storage box underneath the cushion, and the set is equipped with tools for basic maintenance.

PASSENGER HANDRAILS

Passenger handrails are located on the left and right sides of the passenger seat.




⚠ WARNING

Passengers must hold onto the passenger handrail at all times while riding the vehicle and must keep their feet firmly on the foot.

FOOT PEDALS

Pedal serrations are located on the vehicle's foot pedals.



⚠ WARNING


During the operation of the vehicle, both the driver and the passenger must keep both feet on the foot serrations at all times

STORAGE BOX

The vehicle is equipped with 2 storage boxes.


Front storage box

Located on the front right side of the vehicle.



Middle storage box

Located under the cushion, the driver's tool set is placed in this storage box, and the tool contains tools for basic maintenance.




▲ CAUTION

Always lock the storage boxes before riding and never place any fragile, flammable or heavy items in the storage box.

RACKS

Racks are used to carry equipment and various other loads and should never be used to carry people.



WARNING


- Do not carry passengers on racks
- Loads must not interfere with the driver's view.
- The weight of the load must not exceed the maximum load capacity of the rack.

HANDLEBAR ADJUSTMENT

The handlebars can be adjusted to suit the rider's angle.

WARNING

Improper adjustment of the handles or improper torque of tightening bolts can result in limited or loose of handler steering, loss of control can result in severe injury or death. Always follow the adjustment procedure, or check out the services at your dealer.



1 M8×45 (4 PCS)

Torque to specification:

Torque	Handlebar bolts: 35N.m (25 ft·lb)
--------	-------------------------------------

1. Loosen the four handlebar bolts.
2. Adjust the position of the handlebar according to the rider needs.
3. Tighten the two front bolts and then tighten the two rear bolts. Leave a gap of 1/8 (3 mm) at the back of the clamp block.
4. Tighten the fastening bolts.

OPERATION

PRE-RIDE INSPECTION	60
INSPECTION ITEMS	61
BASIC DRIVING GUIDE	62
TRAIL ETIQUETTE	62
KNOW YOUR RIDING AREA/TREAD LIGHTLY	62
VEHICLE BREAK-IN PERIOD	62
BREAK-IN PROCEDURE FOR BRAKING SYSTEM	62
CLUTCH/BELT	63
NEW OPERATOR DRIVING PROCEDURES	63
STARTING THE VEHICLE	63
PARK THE VEHICLE.....	64
TURNING THE VEHICLE	64
DRIVING IN REVERSE	65
TURNING AROUND ON A HILL (K-TURN)	65
DRIVING ON SLIPPERY SURFACES	66
DRIVING THROUGH WATER.....	66
DRIVING OVER OBSTACLES.....	67
DRIVING UPHILL.....	68
DRIVING DOWNHILL	69
DRIVING ON A SIDEHILL	70
PARKING ON AN INCLINE	71
BRAKING	72
PARKING THE VEHICLE	72
BREAK-IN GUIDELINES.....	73
LOAD LIMITS & GUIDELINES	74



OPERATION

MAXIMUM LOADING CAPACITY.....	75
LOADING GUIDELINES.....	75
TRAILER	76
WINCH OPERATION	78

This section provides basic operating instructions, including how to start and stop the vehicle, driving tips and considerations when driving on different roads.

Even if you have ridden other scooters, you must take the time to familiarize yourself with how the vehicle operates. Practice in a flat, wide area until you are familiar with the ATV.

 **WARNING**

Failure to inspect and verify that the vehicle is in safe operating condition before operating increases the risk of an accident. Always perform the pre-riding Inspection outlined in the Operation chapter before use of your vehicle to make sure it's in safe operating conditions. Always follow the inspection and maintenance procedures and schedules described in this owner's manual. See the Periodic Maintenance section in the Maintenance chapter.

PRE-RIDE INSPECTION

Perform a pre-ride inspection before each ride to detect any potential problem that could occur during operation. The pre-ride inspection can help you monitor component wear and deterioration before they become a problem.

Correct any problem that you discover to reduce the risk of a breakdown or crash.

INSPECTION ITEMS

Project	Explanation	Page
Brake system / Lever stroke	Ensure correct operation	P45~P48
Brake Fluid	Ensure proper level	P112~P113
Auxiliary brake	Ensure correct operation	P45
Front suspension	Check, lubricate if necessary	P121
Rear suspension	Check, lubricate if necessary	P121
Tires	Check status and air pressure	P115
Wheel/Lug Nuts	Check, ensure fasteners airtightness	P117
Fuel Level	Ensure proper level	P51
Coolant	Ensure proper level	P108
Indicator light	Ensure display status	P37~P41
Switches	Ensure operation	P28
Engine switch	Ensure correct operation	P30
Headlights	Check operation	P30
Brake light/tail light	Check operation	P30
Riding equipment	Wear approved helmets, care and protective clothing	P14~P15
Trailer(optional equipment)	Check cable and interchanger	---

BASIC DRIVING GUIDE

TRAIL ETIQUETTE

Always practice good etiquette when riding. Allow a safe distance between your vehicle and other vehicles in the same area. Communicate with oncoming operators by signaling the number of vehicles in your group. When stopping, move your vehicle to the edge of the trail to allow others to pass safely.

KNOW YOUR RIDING AREA/TREAD LIGHTLY

Familiarize yourself with all laws and regulations concerning the operation of this vehicle in your area. Respect the environment in which you ride your vehicle.

Find out where the designated riding areas are by contacting your dealer, a local riding club or local officials. Help keep our trails open for recreational vehicle use.

VEHICLE BREAK-IN PERIOD

Your vehicle's run-in period is the first 25 hours of operation or the riding mileage which first two full tanks of gasoline are used up. It's important for you with single operation and proper run-in period. Careful handling of new engine and drive components will improve the performance and service life of these components. Follow these steps carefully.

BREAK-IN PROCEDURE FOR BRAKING SYSTEM

In order to achieve the best brake performance of the new vehicle the brakes must be broken in properly.

Heavy or excessive braking when using the new braking system may damage the brake pad and disc.

CLUTCH/BELT

Proper run-in of the clutch and driving belt will ensure longer service life and better performance. Run the run-in clutch and belt at low speeds for the recommended run-in time by only pulling light loads. Avoid violent acceleration and high speed running during run-in period. If the belt is broken, be sure to clean up the intake and outlet pipeline and any debris from the clutch and engine compartment during belt replacement.

NEW OPERATOR DRIVING PROCEDURES

1. Wear protective riding gear. See the Safe Riding Gear section.
2. Perform the pre-ride inspection.
3. Place the transmission in Parking gear.
4. Mount the vehicle from the left side.
5. Sit upright with both feet on the footrests and both hands on the handlebars.
6. Start the engine to warm up.
7. Drive slowly. Practice maneuver and use the throttle and brakes on level surfaces.

STARTING THE VEHICLE

1. Turn the ignition switch key to the "ON" position.
2. Step forcefully on the foot brake or press forcefully on the brake handle, and place the transmission "N" gear.
3. Press the engine start/stop switch to the "(⚡)" position then release it to start the engine.
4. The vehicle is started. Step forcefully on the foot brake.

PARK THE VEHICLE

1. Step on the foot brake and place the transmission in "P" gear.
2. Press the engine start/stop switch to the "~~⊗~~" position to stop the engine.
3. Turn the key to the "OFF" position, and the key can be removed from the switch.
4. Lock the handle parking brake lever. Step on the foot brake and set the shifter to the "P" position.

TURNING THE VEHICLE

Both rear wheels drive equally at all times. This means that the outside wheel must travel a greater distance than the inside wheel when turning.

1. Slow down.
2. Steer in the direction of the turn.
3. Keep both feet on the footrests.
4. Lean your upper body to the inside of the turn while supporting your weight on the outer footrest. This technique alters the balance of traction between the rear wheels, allowing the turn to be made smoothly. The same leaning technique should be used for turning in reverse.
5. Practice making turns at slow speeds before attempting to turn at a faster speed.



WARNING

**Turning improperly can result in vehicle overturn.
Never turn abruptly or at sharp angles. Never turn at high speeds.**

DRIVING IN REVERSE

If you need to ride in reverse, make sure the area behind you is clear and only operate the ATV at low speed.

Do not use the override switch unless additional wheel speed is required for vehicle movement. Use the override with caution as rearward vehicle speed is greatly increased. Do not operate at wide open throttle. Operate the throttle just enough to maintain a desired speed.

To reverse, follow the following procedure:

1. Always check for obstacles or people behind the vehicle, be sure there are no obstacles or people in the way.
2. Press the brake to change the shifter to "R".

TURNING AROUND ON A HILL (K-TURN)

If the vehicle stalls while climbing a hill, never back it down the hill! Use the K- turn to turn around.

1. Stop and lock the parking brake while keeping body weight uphill.
2. Leave the transmission in forward and shut off the engine.
3. Dismount on the uphill side of the vehicle, or on the left if the vehicle is pointing straight uphill. Staying uphill of the vehicle, turn the handlebars full left.
4. While holding the brake lever, release the parking brake lock and slowly allow the vehicle to roll around to your right until it's pointing across the hill or slightly downwards.
5. Lock the parking brake. Remount the vehicle from the uphill side, keeping body weight uphill. Start the engine with the transmission still in forward.
6. Keep the transmission in forward and start the engine.
7. Release the parking brake and proceed slowly, control speed with the brake lever, until the vehicle is on flat ground.

DRIVING ON SLIPPERY SURFACES

Whenever riding on slippery surfaces such as wet trails or loose gravel, or during freezing weather, follow these precautions:

1. Do not operate on excessively rough, slippery or loose terrain.
2. Slow down when entering slippery areas.
3. Engage 4X4 before wheels begin to lose traction.

NOTICE

Severe damage to drive train may occur if the 4X4 is engaged while the wheels are spinning. Allow the rear wheels to stop spinning before engaging 4X4, or engage 4X4 before wheels begin to lose traction.

4. Maintain a high level of alertness, reading the trail and avoiding quick, sharp turns, which can cause skids.
5. Never apply the brakes during a skid. Correct a skid by turning the handlebars in the direction

DRIVING THROUGH WATER

Your ATV can operate through water with a maximum recommended depth equal to the bottom of the footrests. Follow these procedures when operating through water:



⚠ CAUTION

Major engine damage can result if the vehicle is not thoroughly inspected after operation in water. Perform the services outlined in the Periodic Maintenance Chart. The following areas need special attention: engine oil, transmission oil, demand drive fluid and all grease fittings. If the vehicle tips or overturns in water, or if the engine stops during or after operating in water, service is required before starting the engine. Your dealer can provide this service. If it's impossible to bring the vehicle in before starting the engine, perform the service outlined in the Vehicle Immersion section of this manual, and take the vehicle in for service at the first opportunity.

1. Determine water depths and current before entering water.
2. Choose a crossing where both banks have gradual inclines.
3. Avoid operating through deep or fast-flowing water.
4. After leaving water, test the brakes. Apply them lightly several times while driving slowly. The friction will help dry out the pads. If it's unavoidable to enter water deeper than the footrest level:
 - Proceed slowly. Avoid rocks and obstacles.
 - Balance your weight carefully. Avoid sudden movements.
 - Maintain a steady rate of speed. Do not make sudden turns or stops. Do not make sudden throttle changes.

DRIVING OVER OBSTACLES

Follow these precautions when operating over obstacles:

1. Before operating in a new area, check for obstacles.
2. Watch out for bumps, potholes and other obstacles in the terrain.

3. When you approach any obstacle, reduce your speed and be prepared to stop.
4. Never try to ride over large obstacles, such as large rocks or fallen logs.
5. Always have a passenger dismount before operating over an obstacle that could cause a fall from the vehicle or vehicle tip over.



DRIVING UPHILL

Braking and handling are greatly affected when operating in hilly terrain. Improper procedure could cause loss of control or rollover. Whenever traveling uphill, follow these precautions:

1. Drive straight uphill.
2. Avoid steep hills.

Maximum incline is:

- **No passenger: 25°**
- **With passenger: 15°**



No passenger: 25°



With passenger: 15°

3. Always check the terrain carefully before ascending any hill.
4. Never climb hills with excessively slippery or loose surfaces.
5. Keep both feet on the footrests.
6. Shift body weight uphill. A passenger should also shift body weight uphill.
7. Proceed at a steady rate of speed and throttle opening. Opening the throttle suddenly could cause the ATV to flip over backwards.

DRIVING DOWNHILL

When driving downhill, follow these precautions:

1. Avoid steep hills.

Maximum incline is:

- **No passenger: 25°**
- **With passenger: 15°**



No passenger: 25°



With passenger: 15°

2. Always check the terrain carefully before descending a hill.
3. Always descend a hill with the transmission in forward gear. Do not descend a hill with the transmission in neutral.
4. Slow down. Never travel down a hill at high speed.
5. Drive straight downhill. Avoid traveling down a hill at an angle, which would cause the vehicle to lean sharply to one side.
6. Shift body weight uphill. A passenger should also shift body weight uphill.
7. Apply the brakes slightly to aid in slowing. Applying the brakes too firmly may cause the rear wheels to lock, which could result in loss of control.

DRIVING ON A SIDEHILL

Driving on a sidehill is not recommended. Improper procedure could cause loss of control or overturn. Avoid crossing the side of any hill unless absolutely necessary.

If crossing a sidehill is unavoidable, follow these precautions:

1. Slow down.
2. Avoid crossing the side of a steep hill.

3. Lean into the hill, transferring your upper body weight toward the hill while keeping your feet on the footrests.



4. If the vehicle begins to tip, quickly turn the front wheel downhill, if possible, or dismount on the uphill side immediately!

PARKING ON AN INCLINE

Avoid parking on an incline if possible. If it's unavoidable, follow these precautions:



1. Stop the engine.
2. Place the transmission in PARK.
3. Lock the parking brake.
4. Always block the rear wheels on the downhill side.

BRAKING

1. Release the throttle pedal completely. (When the throttle pedal is released completely and engine speed slows to near idle, the vehicle has no engine braking.)
2. Press on the brake pedal evenly and firmly. Practice starting and stopping (using the brakes) until you're familiar with the controls.



PARKING THE VEHICLE

1. Stop the vehicle on a level surface. When parking inside a garage or other structures, be sure that the structure is well ventilated and that the vehicle is not close to any source of flame or sparks, including any appliance with pilot lights.
2. Place the transmission in PARK.
3. Turn the engine off.
4. Engage the parking brake (if equipped).
5. Slowly release the brake pedal and make sure the transmission is in PARK before exiting the vehicle.
6. Remove the ignition key to prevent unauthorized use.

BREAK-IN GUIDELINES

The engine needs 10 working hours or a 186 mi (300km) run-in period.

During run-in:

- Avoid full throttle operation.
- Avoid pressing the accelerator pedal for more than 3/4 stroke.
- Avoid continuous acceleration.

The brake needs a 124 mi (200km) run-in period.

New brakes will not operate at their maximum efficiency until the run-in period is over. Brake performance may be compromised, so be careful.

NOTICE

During this period, avoid full-throttle starts, rapid acceleration and constant rpm operation.

LOAD LIMITS & GUIDELINES

The front and rear shelves of your vehicle are capable of carrying goods, and the towing device behind the vehicle can also carry the load.

Any load carried by the vehicle will affect the vehicle's operation, stability and braking distance. Do not exceed the vehicle load limit, including driver, passenger, cargo, components weight, and traction rod weight. It is important to be aware that the cargo may slip or fall to cause an accident

WARNING

- **Strictly follow the instructions outlined in the owner's manual of the mounted or trailed machinery or trailer, and not to operate the combination tractor-machine or tractor-trailer unless all instructions have been followed.**
- **Stay clear from the area between vehicle and trailer.**
- **Reduce speed and allow greater braking distance when carry goods.**
- **The lower the height of the goods on the shelf, the better. Too much cargo on the shelves can destabilize the vehicle's center of gravity and reduce driving stability.**
- **Fix all goods before operation. Unstable cargo can create unstable driving conditions, which can make the vehicle lose control.**
- **Heavy loading causes braking and control problems. Take extra care when using the brakes of a loaded vehicle. Avoid terrain or conditions that may recede downhill.**

⚠ WARNING

- Take extra care when carrying goods beyond the edge of the shelf. Stability and mobility may be adversely affected, causing the vehicle to tip over.
- Do not block the headlight beam when loading on the front shelf.
- Don't drive faster than recommended speed. Vehicles should not exceed 9 MPH (15 km/h) when towing a load on a flat ground. Towing loads, turning, climbing or descending over rough terrains must not exceed a speed of 5 MPH (8 km/h).

MAXIMUM LOADING CAPACITY

Don't go beyond the maximum loading capacity.

Vehicle Model	SGW500F-A7	SGW500F-A8
Front Shelf	40KG	40KG
Rear Shelf	60KG	60KG
Maximum unbraked towing mass	150 kg	150 kg
Maximum unbraked tongue mass	100 kg	100 kg
Maximum inertiabrated towing mass	600 kg	600 kg
Maximum inertiabrated tongue mass	100 kg	100 kg

LOADING GUIDELINES

When transporting cargos, please follow below instructions:

1. Do not exceed the weight specified in the warning label and this manual.
2. Never ride with a passenger on the front or rear cargo racks.
3. Always load the goods on the shelf as far forward as possible. Ensure that the goods loaded on the rack are firmly secured before driving. If the cargo is not secured, it will cause

unexpected dumping.

4. Make sure all cargo is secured before riding.
5. Avoid riding on steep slopes when carrying cargo or pulling a trailer.
6. Use low-speed gear when hauling heavy cargo.
7. When handling cargo, operate the vehicle with caution.

TRAILER


The towing device is a detachable part. It can be removed from the ATV if you are not using a trailer. If you need to tow a load, please be remained that the towing weight does not include the towing device.

- The combination of the weight of the rear rack and the traction rack shall not exceed the capacity of the rear rack.
- The total load (weight on the operator, accessories, cargo and trailer) shall not exceed the maximum capacity of the vehicle.

Where a designated attachment point is provided on the towbar:


Either:


Pass the cable through the attachment point and clip it back on itself.



Or:

Attach the clip directly to the designated point, this alternative must be specially permitted by the trailer manufacturer since the clip may not be sufficiently strong for use in this way.





NOTICE

The speed must be less than 9 MPH (15 km/h) during towing.

Improper use of hooks or exceeding the maximum towing weight capacity may cause serious damage to your vehicle. In this case, your ATV will not be covered by service policy.

Do not install trailers larger than 4 inches (10 cm). Never install vehicle accessories on the ATV. Always install accessories approved (or equivalent) designed for ATV use.

WINCH OPERATION

If your vehicle is equipped with a winch, please read this manual before installation and understand and be familiar with the relevant safety precautions and operating instructions.

WARNING

The user must read and understand the operating instructions and warnings of this operation manual. If the instructions or warnings are not followed, serious property damage or personal injury may occur.

- It is strictly prohibited for people under 16 years old to use this equipment.
- The user must read and understand the operating instructions and warnings of this operating manual. If the instructions or warnings are not followed, serious property damage or personal injury may occur.
- Before operation or during use, pay attention to the safety and environmental conditions within the operating range of the winch.
- Do not overload. Ensure that all equipment used meet the maximum rope pull force rating. We recommend using an optional pulley block, double rope using a pulley block double rope to reduce the load on the winch, rope and battery. When double rope, the rated value of the pulley block should be two times the rope pull of the winch.
- Under heavy load, do not try to pull for a long time. Electric winches are only designed for intermittent use, should not be used under constant load. Do not pull for more than one minute or close to the rated load. If the winch motor feels very hot, stop winch and let it cool for a few minutes.

- The rope end cannot bear the full load, and the rope must rotate around the drum at least 5 laps.
- Avoid pulling from extreme angles, as this will cause the rope to be rolled on one end of the barrel and damage the rope.
- Note that the rope-drawing capacity of the winch is the maximum rope-drawing capacity of the first layer, only the first the layer can only be pulled, do not operate the winch with overload capacity.
- Never hook the rope back to itself, otherwise the rope will be damaged. Use trunk protection protector.
- Before operation, make sure that the winch is firmly installed on the vehicle or bracket.
- Before moving heavy objects, check the wire rope to prevent kinks and uneven wire layers. The slack rope must be properly tightened under a weight of about 200.46 pounds.
- When pulling the load, be sure to lay a blanket or protective layer on the wire rope near the hook end. This will prevent the possibility of breaking the wire rope and help prevent serious injuries and damage.
- Do not move the winch to assist in hauling heavy objects. It is easy to overload and cause damage to the wire rope.
- Pay attention to the dangerous areas and stay away from them during the operation. Dangerous areas are winch drum, fairlead, wire rope, pulley block, hook and motor.
- When the winch is under load, do not approach or cross the rope.
- When using the hoist to move the load, place the vehicle transmission in neutral and apply brake of the vehicle and plug all wheels with wedges. When the hoist is working, the vehicle engine should be operated to fully charge the battery. Never use the hoist with insufficient voltage.

- Never disconnect the power supply when there is a load on the winch.
- After the operation, please release the load immediately, and do not tighten the cable.
- Always stay away from ropes, hooks and winches.
- Check winches, ropes, hooks, and broken strands of worn wires regularly. When handling the steel wire rope, please wear thick leather gloves. Do not let the steel wire rope slip over your hands. Check the steel rope before use. The crushed, pinched, worn or kinked area has seriously reduced the carrying capacity. The damaged steel wire rope should be replaced. It must be re-wound under a load of about 100 pounds.
- The clutch should be disconnected first, and then the wire rope should be pulled by the hook of the protective lever. Do not pull the wire rope directly through the hook with your fingers.
- Maintain the specified tension so that the cable can be wound on the reel and re-rolled after the operation tight.
- Do not operate the winch under the influence of alcohol or drugs. In operation, be vigilant during the process. If there is a problem, you should cut off the battery immediately and check it-carefully.
- Wear goggles, insulating overalls, non-slip shoes, work caps, thick leather gloves. Place your hair tightly under the work cap and remove all jewelry.
- Do not mechanically process or melt any part of the winch.
- When the winch is in use, be sure to start the vehicle engine and set the gear position to "N" to make sure battery is charging.
- When the winch is working, the current is large, so you must start the vehicle and step on the accelerator lightly to avoid

damage to the battery.

- The winch rope and the vehicle should be in a straight line. Too big an angle will change the direction of the pulling force, thereby damaging the rope.
- If severe noise or vibration occurs during the use of the winch, it must be stopped immediately.
- When the winch is not used, please remove the controller.

WARNING

When releasing or retrieving the winch rope, both ends of the rope must be left with sufficient length to prevent the rope from being over-rolled in or out. When the rope is retrieving, please maintain a certain tension so that the wire can be retracted smoothly and can be wound tightly during retrieving.

WARNING

Always use the tow rope to pull the hook. Do not hold the hook with your hands. This is not only important when winding the wire rope, but also when removing the wire rope from the winch under power.



MAINTENANCE, STORAGE AND TRANSPORTATION

PERIODIC MAINTENANCE	85
LIFTING AND SUPPORTING THE VEHICLE	90
AIR FILTER COVER	91
FRONT PANEL MAINTENANCE COVER REMOVED	92
LUBRICATING OIL	93
ENGINE OIL MAINTENANCE PROGRAM.....	94
OIL RECOMMENDATION	94
ENGINE OIL LEVEL CHECK.....	95
CHANGING ENGINE OIL AND FILTER.....	97
DRAIN THE ENGINE OIL.....	98
OIL STRAINER CLEAN.....	99
OIL FILTER CHANGE	100
ADD OIL	101
FRONT/REAR GEAR BOX LIQUID	102
FRONT/REAR AXLE GEAR OIL CHECK.....	102
FRONT/REAR AXLE GEAR OIL	103
CTV DRIVE BELT.....	104
BELT REPLACEMENT/DEBRIS REMOVAL	104
INSTALL DRIVE BELT	105
CVT DRYING.....	106
COOLANT.....	107
RADIATOR INSPECTION	107
COOLANT LEVEL CHECK/ADDT	108
REPLACE ENGINE COOLANT	108
AIR FILTER.....	109

MAINTENANCE, STORAGE AND TRANSPORTATION

CVT AIR INTAKE FILTER	110
CVT INTAKE FILTER CHECK	110
BRAKE SYSTEM	111
BRAKE OIL.....	112
FRONT BRAKE FLUID	113
BRAKE COMPONENT.....	113
TIRE	115
TIRE PRESSURE	115
TREAD DEPTH OF TIRE.....	116
REPLACE THE TIRES.....	116
WHEEL COMPONENT REMOVAL	117
TIRE REPLACEMENT.....	118
SHOCK ABSORBER ADJUSTMENT	119
OIL SHOCK ABSORBER	119
ADJUSTABLE AIR SHOCK ABSORBER	120
SUSPENSION DRIVE LUBRICATION	121
FRONT (REAR) DRIVE SHAFT DUST COVER	122
LAMP	123
LED HEADLIGHT/TAILLIGHT REPLACEMENT.....	123
HIGH BEAM ADJUSTMENT.....	124
SPARK PLUG	126
SPARK PLUG INSPECTION	127
SPARK ARRESTER	129
BATTERY	131
ELECTRONIC POWER STEERING (EPS)	132
BATTERY DISASSEMBLY	133



MAINTENANCE, STORAGE AND TRANSPORTATION

BATTERY INSTALLATION.....	134
BATTERY CHARGING	135
BATTERY INSTALLATION.....	136
FUSE.....	137
FUSE BOX.....	138
FUSE/RELAY DISTRIBUTION AND RATED AMPERAGE.....	139
FUSE BOX REPLACEMENT	141
APPEARANCE CARE	142
VEHICLE WASHING	142
CLEANING TIPS	142
VEHICLE STORAGE	143
TRANSPORTING THE ATV	143

PERIODIC MAINTENANCE

Careful periodic maintenance will help keep your vehicle in the safest, most reliable condition. Inspection, adjustment and lubrication of important components are explained in the periodic maintenance chart.

Inspect, clean, lubricate, adjust and replace parts as necessary. When inspection reveals the need for replacement parts, use genuine parts available from your authorized dealer.

Service and adjustments are important for proper vehicle operation. If you're not familiar with safe service and adjustment procedures, have a qualified dealer perform these operations.

Maintenance intervals in the following chart are based upon average riding conditions. Vehicles subjected to severe use must be inspected and serviced more frequently.

Severe use is defined as:

- **Frequent immersion in mud, water, or sand**
- **Frequent or prolonged operation in dusty environments**
- **Short trip cold weather operation**
- **Racing or racing-style high RPM use**
- **Prolonged low speed, heavy load operation**
- **Extended idle**

MAINTENANCE CHART KEY

SYMBOL	DESCRIPTION
▶	Perform these procedures more often for vehicles subjected to severe use.
D	Have an authorized dealer or other qualified person perform these services.

WARNING

Improperly performing the procedures marked with a D could result in component failure and lead to serious injury or death. Have an authorized dealer or other qualified person perform these services.

Perform all services at whichever maintenance interval is reached first. Record maintenance and service in the Maintenance Log.

PRE-RIDE MAINTENANCE

ITEM	MAINTENANCE INTERVAL (WHICHEVER COMES FIRST)			REMARKS
	HOURS	CALENDAR	MILES (KM)	
Steering		Pre-Ride		Visually inspect, test, or check components. Make adjustments and/or schedule repairs when required
Front suspension		Pre-Ride		
Rear suspension		Pre-Ride		
Tires/ Wheels/ fasteners		Pre-Ride		
Brake fluid level		Pre-Ride		
Brake system		Pre-Ride		
Accelerator		Pre-Ride		
Engine oil level		Pre-Ride		
Air filter, pre-filter		Daily		Inspect. clean often. replace as needed
Coolant		Daily		Check level
Power steering unit (if equipped)		Daily		Inspect daily. clean often.
Headlight/ taillight/ worklight		Daily		Check operation. apply dielectric grease if replacing lamps

BREAK-IN MAINTENANCE

ITEM	MAINTENANCE INTERVAL (WHICHEVER COMES FIRST)			REMARKS
	HOURS	CALENDAR	MILES (KM)	
Fuel System	25 H	1 M	200 (320)	Break-in check: cycle key to pressurize fuel pump; check lines and fittings for leaks and abrasion
Engine oil change	25 H	1 M	620 (1000)	Break-in check: oil and filter change
Front gearcase oil	25 H	1 M	200 (320)	Break-in check: oil level check
Rear gearcase oil	25 H	1 M	200 (320)	Break-in check: oil level check

PERIODIC MAINTENANCE

Make sure to perform proper maintenance at recommended intervals as indicated in the tables. Some items of the maintenance schedule must be performed in function of the calendar, regardless of the distance or time of operation.

ITEM	MAINTENANCE INTERVAL (WHICHEVER COMES FIRST)			REMARKS
	HOURS	CALENDAR	MILES(KM)	
▶ Brake pad wear	10 H	Monthly	100 (160)	Inspect periodically; replace as needed
Battery	20 H	Monthly	200 (320)	Check terminals; clean; test
▶ Air filter, main element	50H		500 (800)	Inspect; replace as needed; inspect frequently if subjected to severe use
▶ General lubrication	50 H	3 M	500 (800)	Lubricate all fittings, pivots, cables, etc.
Throttle Body Intake Duct	50 H	6 M	500 (800)	Inspect duct for proper sealing/air leaks
Drive belt	50 H	6 M	500 (800)	Inspect; adjust; replace as needed
Cooling system	100 H	12 M	1000 (1600)	Inspect coolant strength seasonally; pressure test system yearly
▶ Engine oil change	100 H	12 M	1000 (1600)	Change the oil and filter


PERIODIC MAINTENANCE

ITEM		MAINTENANCE INTERVAL (WHICHEVER COMES FIRST)			REMARKS
		HOURS	CALENDAR	MILES(KM)	
▶	Oil lines and fasteners	100 H	12 M	1000 (1600)	Inspect for leaks and loose fittings
▶	Front gearcase oil	100 H	12 M	1000 (1600)	Change fluid;
▶	Rear gearcase oil	100 H	12 M	1000 (1600)	Change fluid
D	Fuel system/filter	100 H	12 M	1000 (1600)	Cycle key to pressurize fuel pump; check for leaks at fill cap, fuel lines/rail and fuel pump; replace lines every two years
▶	Radiator (if applicable)	100 H	12 M	1000 (1600)	Inspect; clean external surfaces
▶	Cooling hoses (if applicable)	100 H	12 M	1000 (1600)	Inspect for leaks
▶	Engine mounts	100 H	12 M	1000 (1600)	Inspect
	Exhaust muffler/pipe / Joints	100 H	12 M	1000 (1600)	Inspect; clean; replace worn parts
D	Spark plug	100 H	12 M	1000 (1600)	Inspect; replace as needed
D	Clutches (drive and driven)	100 H	12 M	1000 (1600)	Inspect; clean; replace worn parts
D	Front wheel bearings	100 H	12 M	1000 (1600)	Inspect; replace as needed
D	Brake fluid	200 H	24 M	2000(3200)	Change every two years
	Spark arrester	300 H	36 M	3000(4800)	Clean out
▶	Coolant		60 M		Replace coolant
D	Valve clearance	500 H		5000(8000)	Inspect; adjust
	Idle speed				Adjust as needed
D	Toe adjustment				Inspect periodically; adjust when parts are replaced
	Headlight aim				Adjust as needed

LIFTING AND SUPPORTING THE VEHICLE

Place vehicle on a flat non slippery ground. Engage the 4WD mode. Ensure vehicle shift lever is set to PARK.


When lifting the front or rear of the vehicle, place the jack in the left and right center of the front or rear of the vehicle, as shown in the figure below:



Schematic diagram of jack support position

AIR FILTER COVER

The engine oil filling port and spark plug are located under the air filter cover.




1 Air filter cover

2 Hexagon screws

1. First remove the seat.
2. Use a tool to remove the two hex screws behind the air filter cover.
3. Remove the air filter cover.

FRONT PANEL MAINTENANCE COVER REMOVED

Coolant filler, fuse box, brake fluid cup, etc. are located below the service cover.



To remove the front panel service cover, do the following: :

Remove the fasteners from the front shelf assembly and remove the quick-detachable front panel maintenance cover.

LUBRICATING OIL

Check and lubricate all components at the intervals listed in the periodic maintenance chart. Items not listed in the chart should be lubricated in the general lubrication interval. The rocker arm is lubricated at the factory and does not require additional lubrication. However, if these components are heavily used, the user may perform additional lubrication as required.

Project	Recommended model	Capacity	Inspection procedure
Engine oil	SAE 10W-40 SJ or higher	2.2 L	Maintain level in safe range on dipstick
Front axle gear oil	SAE 80W-90 GL-5	170 mL	Drive each 2000km(1200MI) Kilometers.
Rear axle gear oil	SAE 80W-90 GL-5	260mL	
Coolant		3000 mL	Maintain the level between the fill lines.
Brake fluid	DOT4		Maintain the level between the fill lines.
Suspension, balance bar grease		---	Grease nozzle (3 Pump max) per 500 mile.

ENGINE OIL MAINTENANCE PROGRAM

Be sure to check and change the oil at the time required by the regular maintenance chart. Be sure to use recommended engine oil. The oil filter must be changed every time the oil is changed. Pay special attention to the oil level. An increase in the oil level during cold weather can indicate contaminants collected in the oil sump or crankcase. If the oil level starts to rise, change the oil immediately. Monitor the oil level, if it continues to rise, stop using it and determine the cause. Your dealer can assist.

WARNING

Vehicle operation with insufficient, degraded or contaminated engine oil will cause accelerated wear and tear, and may result in engine jams, accidents and injuries. Always perform the maintenance procedures listed in the periodic maintenance chart.


OIL RECOMMENDATION

Change the oil filter every time you change the oil.

It is recommended to use the recommended type of oil or similar oil for this engine. Follow manufacturer's recommendations for operating at ambient temperature.

CAUTION

Mixing brands or using non-recommended oils may cause serious engine damage. Always use the recommended oil. Never replace or mix oil brands.




ENGINE OIL LEVEL CHECK

NOTICE

Running the engine with an improper oil level can cause serious engine damage.

1. Park the vehicle on a level ground. Wait at least 5 minutes to allow the oil to flow back to the bottom of the engine.
2. Put a piece of cotton cloth under the end of the oil dipstick, and then pull out the oil dipstick.
3. Wipe the oil dipstick clean.
4. Reinsert completely.
5. Put a piece of cotton cloth under the end of the oil dipstick, then pull out the oil dipstick and check the oil level.

Check the oil level as shown in the figure below. The oil level is between the Upper engraved line and the Lower engraved line. It is the proper oil level. Below the lower scale means the oil is too little, and the upper scale means the oil is too full, too little or too full is not suitable.



1 Oil dipstick

2 Top line

3 Bottom line

6. After cleaning the oil dipstick, fully insert it again.
7. If the oil level is near or below the lower level mark, remove the seat. Remove the oil fill cap from the front right crankcase cover and add the specified oil into the fill cap hole up to the upper level mark on the dipstick.
8. Reinstall the oil fill cap and dipstick.
9. Install the tank cover assembly.
10. Install the seat.

CHANGING ENGINE OIL AND FILTER

This procedure requires certain mechanical skills, specialized tools (torque wrenches), and how to handle the discharge of fluids. If you don't have the skills or tools, consult your dealer.


NOTICE

Whenever changing oil, it is recommended to change the oil filter.

WARNING

- **The used engine oil contains potentially hazardous pollutants which can cause skin diseases such as dermatitis and skin cancer so take care to avoid prolonged and repeated exposure to such oils. Wash the skin thoroughly with soap and water to remove the used engine oil.**
- **The used oil and filtration must be scrapped in a safe and compliant way with environmental regulations. Do not dispose of used oil and filters in domestic garbage, sewers or on the ground. For information on oil recycling or scrapping, please consult your Segway dealer.**
- **Do not put used engine oil in a place where children can reach.**

DRAIN THE ENGINE OIL



- 1 Bolt** **2 Filter inspection cover** **3 Oil drain plug** **4 Gasket**

The engine oil drain plug is located under the maintenance cover plate of the frame floor at the bottom of the vehicle.

- Put the vehicle on the flat level surface.
- Start the engine, let it warm up at idle for 2 to 3 minutes.
- Turn off the engine.
- Remove the fixing screws of the filter inspection cover and open the filter inspection cover.
- Remove the oil drain plug **3** and gasket, until the waste engine oil drains out completely.

NOTICE

Hot oil may burn the skin. Do not let the oil contact skin.



- Put a new sealing washer onto the drain plug and reinstall the drain plug.

Torque specifications :

Torque	Oil drain plug: 16-20N.m(11.8-14.8ft-lb)
--------	--

OIL STRAINER CLEAN

The oil filtration on this engine is a two-stage filtration system. The oil strainer(pre-filter) is designed to trap large foreign objects. Replace the oil according to the Maintenance Schedule. Also use Segway approved oil that is designed for 4-stroke engines.



1 Bolt M6*25*8

2 Strainer cover

3 O-rings seal

4 Strainer spring

5 Oil strainer


The oil filter can be checked after the oil is discharged. If cleaning is needed, please take the following steps:

1. Remove 4 bolts with tools.
2. Remove the strainer cover, O-ring seal and strainer spring in turn.
3. Take out the oil strainer for cleaning.
4. The installation step is opposite to the removal step.

OIL FILTER CHANGE

This procedure requires mechanical skill and professional tools such as a torque wrench as well as a means for disposing of the drained fluid. If you do not have the skills or the tools, see your dealer.

The oil filter is located behind the maintenance cover of the frame bottom plate.




1. Remove the screw of the frame bottom maintenance cover plate, remove the frame bottom maintenance cover plate, the oil filter is located here, put the towel under the oil filter.
2. Remove the oil filter with the oil filter wrench.
3. Replace the new O-ring, lubricate it with lubricating oil and install it on the new filter.
4. Tighten the new filter to the specified torque.

Rotate clockwise to install the new filter until the filter gasket touches the sealing surface. Tighten the can.

NOTICE

Change the oil filter every time you change the oil.

ADD OIL



1 Top line **2** Bottom line **3** Oil filling port

The oil dipstick can be used to add oil.

1. Pull out the oil dipstick.
2. Add the appropriate amount of recommended model oil, do not overfill, the oil level is located between the upper scale and the lower scale is the appropriate oil level.
3. Tighten the oil gauge again.
4. Put the shifter in park gear.
5. Lock the parking brake.
6. Start the engine and let it idle for 1 to 2 minutes.
7. Stop the engine.
8. Check for leaks.
9. Check the oil level and add oil as needed so that the oil level reaches the mark on the dipstick.
10. Dispose of used filters and oil properly.

FRONT/REAR GEAR BOX LIQUID

Please check and replace the required driving fluid at intervals listed in the periodic maintenance chart.


NOTICE

If the front gearbox makes excessive noise during 4WD operation, please change the demand drive fluid. If the noise continues, please ask Segway Powersports dealers or other qualified service facilities for vehicle inspection and service.

Use recommended oil. The use of other liquids may cause improper operation of parts.

FRONT/REAR AXLE GEAR OIL CHECK


The liquid level of the front and rear axle should reach the bottom of the thread of the filling hole, as shown in the figure below:



1. Position the vehicle on a horizontal surface and remove the filling plug.
2. Check the liquid level of the front and rear axles.
3. If the liquid level is at the appropriate level, the appropriate amount of recommended liquid should be added.
4. Reinstall the drain plug.
5. Check for leaks. Dispose of used liquids properly.

FRONT/REAR AXLE GEAR OIL

The filling plugs of the front and rear axle are located on the left side of the axle body, and the drain plugs are located at the bottom of the axle body.



1 Filling plug

2 O-ring

3 Drain plug

1. Position the vehicle on a level surface. Remove filling plug.
2. Remove the oil drain plug and O-ring, so that the grease in the axle body is completely discharged.
3. Clean and reinstall the exhaust plug and O-ring. If the O-ring is aging, replace it with a new O-ring.
4. Reinstall the drain plug and O-ring according to the recommended torque.
5. Add the appropriate amount of recommended oil, the level should reach the bottom of the filling hole thread.
6. Reinstall the filling plug and O-ring according to the recommended torque.
7. Check for leaks and properly dispose of used liquids.

Torque

Drain Plug: 11.8-14.8ft-lb. (16~20N.m)

NOTICE

Dispose of used fluid properly.

CTV DRIVE BELT


Check the CVT drive belt according to the time specified in the vehicle maintenance schedule. If the CVT belt is damaged, it should also be replaced.

BELT REPLACEMENT/DEBRIS REMOVAL

When replacing belts, remove debris from pipes and clutches.

WARNING

Failure to remove all debris when replacing belts may result in vehicle damage, loss of control and serious injury or death.




Remove drive belt

Stop vehicle engine before replacement and allow vehicle to cool fully.

1. First remove the right cover of the vehicle.
2. Remove the CVT anti-ironing board on the CVT.
3. Remove the CVT cover bolt and remove the CVT cover and CVT cover sealing ring.



CVT BELT
MARKING

4. with the kit-out pin for driven pulley (special tool) against the driven wheel as shown in the figure of the hole, make the driven wheel open.

⚠ WARNING

Before removing the drive belt, please note the direction of the marks on the drive belt (such as manufacturer name, arrow mark, etc.) so that the drive belt can be reinstalled on the pulley in the original direction.

5. Take out the drive belt to be replaced, and clean up the debris in the CVT compartment.

INSTALL DRIVE BELT

⚠ CAUTION

Ensure that the new belt direction is consistent with the original belt installation direction.


- The installation procedure is basically the opposite of the disassembly procedure.
- Wrap the drive belt around the CVT drive wheel and drive wheel.
- Pull out the kick-out pin from the drive wheel and tighten the CVT driven wheel.
- Install the CVT seal ring and tighten the CVT cover.

Torque

CVT outer cover bolt: 10 N·m

CVT DRYING

In some cases, water may inadvertently soak into the CVT system, so let it dry before driving.



1. Remove the clutch drain plug.
2. After the water drains out, reinstall the water drain plug.
3. Put the transmission in "P" and pull up the parking handle.
4. Start the engine.
5. Use different throttles for 10-15 seconds to drain moisture and air, dry the belt and CVT. Do not leave the throttle on full throttle for more than 10 seconds.
6. Allow the engine speed to remain at idle speed. Use the brakes. Shift the transmission to the lowest available range.
7. Belt slip test, if the belt slips, repeat the process.
8. If your vehicle needs service, Segway dealers can help.

COOLANT

Control or maintain engine coolant levels through a recovery system. The recovery system components are the auxiliary tank, radiator, radiator pressure cap and connection hose.

As the operating temperature of the coolant increases, the expanded (heated) excess coolant is forced out of the engine, through the pressure cap, and into the recovery bottle. When the engine coolant temperature drops, the contracted (cooled) coolant is drawn out of the bottle, passes through the pressure cap, and enters the radiator.

It is normal for coolant levels to drop on some new vehicles because the system is draining residue. Check coolant level and add coolant to recovery bottle as recommended.

RADIATOR INSPECTION


Check radiators and hoses for leaks or any damage. Check the heat sink, the heat sink must be kept clean, often clean the heat sink in the dirt, and any deposits that hinder the normal cooling of the radiator.

 **CAUTION**

Never clean the radiator when it is very hot.

COOLANT LEVEL CHECK/ADDT

The recovery bottle is located on the left side of the vehicle.



1 Maximum

2 Minimum

1. Observe the liquid level in the bottle
2. If the liquid level is low, remove the cap and add coolant. Maintain the coolant level between the minimum **2** and maximum **1** marks on the bottle (when the liquid is cool).
3. Remove the front panel maintenance cover in the middle area of the front upper part of the vehicle .
4. Unscrew the lid and pour in new coolant. Pay attention to the position of the coolant when pouring in, and do not exceed the maximum liquid level.
5. Tighten the lid of the cooling bottle
6. Reinstall the instrument cover and confirm whether the instrument cover is installed

REPLACE ENGINE COOLANT

To ensure that the coolant maintains its ability to protect the engine, we recommend that the system be completely emptied every five years to add a new coolant, which requires expertise and can be replaced by taking the vehicle to a Segway dealer.


AIR FILTER

The air filter element of the vehicle is a paper air filter element, and the vehicle needs to be cleaned or replaced after a period of use, as shown in the periodic maintenance table.

First remove the filter element to check, if the filter is soaked with oil or serious ash, this situation should not be cleaned, should be directly replaced with a new filter element.

If there is no oil immersion or serious ash, you can put the intake side down, lightly knock on the ground, most of the dust can fall off after vibration, if there is an air pump, you can use the air pump from the filter side to blow out (not from the intake side to blow in), blow the dust off, blow clean.

Remove the air filter cover



1 Air filter cover

2 Air box cover clamp

3 The filter element

4 Air filter plug

The air filter is located under the air filter cover in front of the cushion, and the replacement steps are as follows:


1. Press and move the air box cover clamp.
2. Pull up the front air filter cover.
3. Take out the old air filter.
4. Clean the filter.
5. Install a new filter if necessary.
6. Make sure the air filter is securely anchored.

CVT AIR INTAKE FILTER

The frequency of inspection and cleaning of the CVT air intake filter shall be adjusted according to the driving conditions.

CVT INTAKE FILTER CHECK

It is recommended to regularly check the CVT intake filter, which should be checked according to the following procedures: There are two CVT air intakes, both located under the seat cushion.



1 Air inlet 1 **2 Air inlet 2**

Clean the CVT air inlet filter and replace it with a new air inlet filter if necessary.

BRAKE SYSTEM

The front and rear brakes are hydraulic disc brakes that are activated by moving a single brake lever towards the handlebars. These brakes are self-regulating. As the brake disc wears away, the brake fluid level will drop, and the leakage in the system will cause the fluid level to drop.

WARNING

Brake fluid levels must be checked periodically: overfilling of the brake cylinder may cause brake resistance or brake locking, which may result in serious injury or death. Keep brake fluid at the recommended level and do not overfill. Must check brake disc wear condition regularly: if brake disc wear, should be replaced.

The following inspection is recommended to keep the braking system in good working condition. If the brake is in heavy use during normal operation, check it frequently.

1. Always keep the brake fluid at an appropriate level. Please refer to master cylinder/brake fluid section for details.
2. Check the braking system for liquid leakage.
3. Check whether the brake travels too long or feels soft.
4. Check whether the friction gasket is worn, damaged or loose. When replacing the brake gasket, the brake pad must be replaced when the remaining limit thickness of the brake pad is not less than 1.5 mm.
5. Check the safety and surface condition of the disc. Use the recommended brake cleaner or liqueur to clean any grease. Do not use spray lubricants or other petroleum-based products. If any damage (crack, excessive corrosion, warping) is found, please check the dealer's service before operation.


BRAKE OIL

Use the recommended brake oil:

Brake Oil	DOT4
------------------	-------------

No adjustment is required for the hydraulic assisted braking system. Check the brake oil level of the auxiliary braking system frequently. If the level is shown to be low, perform the following operations. The brake oil cup is located below the front panel.

1. Remove the front shelf and the lower cover of the instrument. See 93 for the removal method. Observe the liquid level in the container:



1 UPPER

2 LOWER


3. The brake fluid level is most suitable between the upper level and the lower level. If it is lower than the lower level, please add the recommended brake fluid and observe the liquid level.
4. Check whether the brake pads are worn.

NOTICE

Brake fluid can damage plastic and painted surfaces and should be added with caution. If the brake fluid comes into contact with the skin or eyes, flush with plenty of water immediately. If you feel unwell, seek medical advice immediately.

FRONT BRAKE FLUID

Check whether the front brake fluid level is below the minimum liquid level mark on the right handlebar. When the liquid level is below the minimum liquid level, perform the following operation.



LOWER mark


1. Replenish brake fluid.
2. Check whether the brake pads are worn.

BRAKE COMPONENT

Brake component consumption will depend on the severity of operating and operating conditions. The brake component consumes faster in wet and muddy conditions. Periodically inspect brake component for consumption according to the maintenance periodic table. If the brake pad thickness is less than

or equal to minimum thickness of 1.5 mm, the brake component must be replaced.

Brake components thickness	Standard thickness	5.0 mm
	Minimum thickness	1.5 mm
Disc thickness	Standard thickness	5.0 mm
	Minimum thickness	4.0 mm



TIRE

TIRE PRESSURE

Driving a vehicle with incorrect tire pressure may result in the following consequences:

- Reduce fuel efficiency
- Reduced driving comfort and shortened tire life
- Safety reduction

When checking tire pressure, follow the below instructions:

Recommended tire pressures	Front wheels	Rear wheels
	7.0psi (48.3kPa)	7.0psi (48.3kPa)

- Inspection can only be carried out after the tire cools down.
- If the vehicle has been parked for at least 3 hours, or has not driven more than 1.5km. Rechecking at this time can get an accurate reading of the cold tire inflation pressure.
- Do use tire pressure gauges. Tire appearance can sometimes be misleading. In addition, even a few pounds less air in a tire can affect driving and handling performance.
- Don't reduce the tire pressure after driving. Increased tire pressure is normal after driving.

TREAD DEPTH OF TIRE

Look at the tire shoulder for the tire wear limit warning mark "T.W.I", following the triangle symbol mark to look past, found that the tire tread has the corresponding bump, when the pattern block convex wear to the bump position, it should replace the tire, otherwise it will be due to insufficient strength, midway burst.



When to change a tire:

- If it is found that the tire is damaged, such a cut, delamination, deep cracks or bulging, tire replacement is needed.
- Tires often have air leaks and cannot be normally repaired due to the size or position of incisions or other injuries. If you are not sure, consult your dealer.

REPLACE THE TIRES

When the tire tread wear has reached the replacement mark or the tire is damaged due to external force impact, a new tire should be replaced.

WHEEL COMPONENT REMOVAL



Torque to specification:

Torque	Lug Nuts: 70-80N.m (51.6-59 ft-lbf)
---------------	--

1. Stop the engine.
2. Put the shift lever in the "P" position.
3. Lock the parking brake.
4. Loosen the four hub mounting nuts using a tool, but do not remove them.
5. Lift by placing a suitable bracket under the tripod frameThe side of the vehicle.
6. Loosen the four hub mounting nuts using a tool.
7. Remove the entire wheel.

⚠ CAUTION

Any loose lug nuts may cause the tire to fall off during operation which may cause an accident or rollover. Always ensure that all lug nuts are tightened to the required value 70~80N·m (51.6-59 ft-lbf). Do not use lubricating oil or grease on wheel bolts or wheel nuts. Lubricating oil or grease may cause excessive tightening of wheel nuts, resulting in damage to bolt or spoke wheels. In addition, lubricating oil or grease can cause wheel nuts to become loose and wheels may fall off, which can lead to accidents and serious injuries. Remove any lubricating oil or grease from wheel bolts or wheel nuts.

TIRE REPLACEMENT

⚠ WARNING


Do not use wheels of different sizes other than recommended in the User's Manual as this can cause the vehicle to lose control.

	The front wheel	The rear wheel
The recommended size	24×8.00-12	24×10.00-12
	25×8.00-12	25×10.00-12

SHOCK ABSORBER ADJUSTMENT

There are different kinds of shock absorber fitted in ATVs depending on different configurations. Please adjust the shock absorber according to the actual kind fitted in your ATV.

OIL SHOCK ABSORBER



1. There are 5 shock absorption positions, which are used for different loads or driving conditions.

Position 1 : For light load or flat terrain.

Position 2 : Standard position.


Position 3 ~ 5 : When ATV load is heavy, it can be adjusted to this position.

2. Use crescent wrench **6** to adjust the impact spring pressure.

⚠ CAUTION

When adjusting the shock absorption position, always adjust the left and right shock absorption to the same position. Step up or down one position at a time during adjustment. Do not try to make large adjustments which may damage the shock absorber.

ADJUSTABLE AIR SHOCK ABSORBER



1 Compression damping adjustment knob

- Turning the knob clockwise increases the shock's compression damping.
- Turning the knob counterclockwise reduces the compression damping of the shock absorber.

2 Recovering the damping adjusting valve.

Use flat screwdriver to adjust the valve.

- Turning to the "H" direction, the return damping increases.
- Rotating in the "S" direction reduces the return damping.

3 Spring adjusting cap. Adjust spring top end cap with special tool.

- Adjust the end cover spring preload downward to increase.
- Upward adjustment of end cover spring preload decreases.


4 Recovering the damping adjusting valve.

- Rotational recovery damping increases in the direction of "S".
- Turning in the "F" direction reduces the return damping.

SUSPENSION DRIVE LUBRICATION


Grease nipples are reserved for the rear suspension and balance parts of the vehicle. These parts need to be fully lubricated when the vehicle is running. Add suitable butter and lubricate according to the time specified in the maintenance cycle table to make these parts wear reduce and increase service life..

Grease filling label



These parts in the vehicle needs sufficient lubrication, according to the maintenance of the periodic table to add appropriate grease, lubrication, can reduce the wear of these parts, and increase the service life.

FRONT (REAR) DRIVE SHAFT DUST COVER



Check the front and rear drive shaft boots for cuts, cracks, damage or grease leaks. If so, contact your Segway dealer for a replacement.

LAMP

CAUTION

Poor lighting can result in reduced visibility while driving. If the headlight and taillight lenses get dirty, please clean the headlamps frequently and replace burnt headlamps promptly. To ensure optimum visibility, make sure the lights are properly adjusted.

LED HEADLIGHT/TAILLIGHT REPLACEMENT

LED lights are composed of multiple LED lamp beads. If the LED headlights or taillights are damaged, take the vehicle to a dealer for replacement headlight components.

In the following cases, contact your dealer for more information. It doesn't mean malfunction if condensed water appears inside the headlamp lens temporarily. Examples are:

- There are big beads of water inside the lens.
- Condensation of water inside the headlamp.

CAUTION

Heat can cause skin burns. Allow the lights to cool before doing maintenance.

DO NOT touch the headlight shade bulb glass. Fingerprints on the glass can cause premature failure.

HIGH BEAM ADJUSTMENT


The headlight beam can be adjusted slightly up/down. Use the following procedure to make adjustments.

⚠ CAUTION

The following pictures are for reference only. Your model may be slightly different.

It is best to let Segway Powersports dealers adjust if conditions permit.

1. Place the vehicle on a horizontal ground with a headlight position of about 10M.




2. Measure the distance from the floor to the center of the headlights and mark the walls at the same height.
3. Start the engine. Convert headlight switch to high beam.
4. Watch the headlights aim at the wall. The strongest part of the headlight beam should be 2 inches. Measurement on the seat includes weight of the driver.

Headlight beam adjustment up and down

To raise the headlight beam, turn the headlight adjusting screw counterclockwise.


To lower the headlight beam, turn the headlight speed adjustment screw clockwise.



1 Light adjusting screw

Left and right adjustment of the headlight beam

Headlight beam can be adjusted slightly to the left or right.



1 Light adjusting screw

To turn the headlight beam to the left, turn the headlight adjustment screw counterclockwise.

To turn the headlight beam to the right, turn the headlight speed adjustment screw clockwise.


SPARK PLUG

Refer to the recommended spark plug type and clearance specifications. Spark plug torque specification.

⚠ CAUTION

Using unrecommended spark plugs can cause serious engine damage.
Always use the recommended spark plugs or their equivalents.

Spark Plug	Model	Spark Plug Gap
	CPR7EA / B7RTC	0.6-0.8mm




SPARK PLUG INSPECTION

Spark plug condition indicates a well running engine. Check or change the spark plugs with reference to the maintenance time of the periodic maintenance schedule.

⚠ CAUTION

Wear protective gloves to remove the spark plug for inspection. A hot exhaust system and engine will cause burns.



- 1 Bolt**
- 3 Spark plug**

- 2 Ignition coil**
- 4 Spark plug sleeve**

The spark plug is located under the cushion. Please refer to page 91 for removing the cushion.

1. Remove the ignition coil fixing bolts.
2. Take out the ignition coil.
3. The spark plug is located below the ignition coil. Use tool to turn the spark plug cap 1/4 and remove it from the spark plug.
4. Rotate the spark plug counterclockwise and remove it.
5. Inspect the spark plug.

Spark plug normal status: The electrode part is grayish white, grayish yellow or light brown, and the electrode gap is about 0.6-0.8mm.

Spark plug to be replaced: The spark plug appears electrode ablation, carbon deposition, clearance is too large, at this time the spark plug should be replaced.

SPARK ARRESTER

Spark eliminator prevents random sparks from entering other vehicles parts. The following warnings can cause serious injury or death if not followed. Regular maintenance can prevent carbon accumulation, whereas delayed maintenance will reduce engine performance.



WARNING

Make sure the exhaust pipes are cool and the engine has just stopped running. Let pipes completely cool down to avoid getting burned.

To reduce fire hazards, ensure that there are no combustible material in the area when removing spark plugs.

Safety glasses are recommended in this procedure.

The exhaust pipe must be cleaned of accumulated carbon periodically as follows:



1 Bolt M6*16 (3 pieces)

2 Spring washers (3 pieces)

3 Flat washers (3 pieces)

4 muffer spark arrester

1. Remove 3 pieces of M6*16 bolts, spring washers and flat washers.
2. Start the engine and increase its speed about 20 times, and at the same time block the end of the muffer with a towel, and instantly generate the air pressure of the exhaust system.
3. Allow the engine exhaust pipe to cool.
4. Use a soft brush to remove carbon deposits from the spark arrester mesh.
5. Reinstall the spark arrester in reverse order of disassembly, and tighten the fixing screws.

BATTERY

Due to natural discharge and leakage effects of some electrical equipment, the 12V battery will discharge gradually even when the vehicle is not in use. If the vehicle is parked for a long time, the 12V battery may discharge and may not start. Please charge the battery slowly one time for at least within 30 days. This will maintain the battery life.



WARNING

12V batteries contain toxic and corrosive sulfuric acid which may produce flammable explosive hydrogen gas. To reduce the risk of serious injury or death, the following precautions should be observed when handling 12V batteries or working near them:

- **Do not smoke or light a match near a 12V battery.**
- **Avoid splashing electrolyte on eyes, skin and clothes.**
- **Wear safety goggles when working near 12V battery.**
- **Keep children away from 12V batteries.**

Be sure to charge the 12V battery in an open area. Do not charge a 12V battery in a poorly ventilated garage or enclosed room.

ELECTRONIC POWER STEERING (EPS)

When the engine is started, the electronic power steering device (if equipped) starts to work. When the key is turned to the "ON" position the EPS system is energized.

NOTICE

When the key is turned to the "ON" position, the EPS warning indicator lights up briefly. Please refer to P42.


After the key switch is turned to the "OFF" position, the EPS system will be turned off.

If the EPS indicator light continues to light up after the engine is started, it means that the EPS system has failed. Please contact your Segway Powersports dealer.

BATTERY DISASSEMBLY

NOTICE

If the electrolyte overflows, immediately wash it off with a solution of 1 tablespoon baking soda and 1 cup water to prevent damage to the vehicle.



The battery is located below the cushion.

Cut off the power before removing battery.

- 1 Bolt M8*12 (2 PC)**
- 2 Battery plate**
- 3 Protective rubber sleeve**
- 4 Positive and negative anchor bolt cable**
- 5 Positive and negative anchor nuts for cable**

1. Use a tool to remove the battery cover bolt M8×12.
2. Remove the battery pressure plate.

3. Turn up the positive and negative protective rubber sleeves.
4. Remove the battery negative screw and nut and disconnect the black (negative) battery cable.
5. Remove battery positive screw and nut and disconnect red (positive) battery cable.
6. Remove the battery from the ATV.

BATTERY INSTALLATION

NOTICE

To reduce the chance of sparks: Whenever removing the battery, disconnect the black (negative) cable first. When reinstalling the battery, install the black (negative) cable last.

1. Clean the battery cables and terminals with a stiff wire brush. Corrosion can be removed with a solution of one cup of water and one tablespoon of baking soda. Rinse well with clean water and dry thoroughly.
2. Place the battery in the tray.
3. Connect and tighten the red (positive) cable and replace the insulating rubber boot.
4. Connect and tighten the black (negative) cable and replace the insulating rubber boot.
5. Install the battery pressure plate.
6. Tighten the battery pressure plate bolts.

Verify that the cables are routed correctly.

BATTERY CHARGING

NOTICE

When charging, the hydrogen produced by the 12V battery is combustible explosive gas. Therefore, please follow the following precautions before charging:


If charging the 12V battery is still installed in the vehicle, be sure to disconnect the ground cable.

Make sure the power switch on the charger is off when connecting and disconnecting the charger cable to the 12V battery.

Only charge slowly (5A or less). If charge quickly, the 12V battery may explode.

Measures to be taken in an emergency

1. Connect the clamp of the positive jumper cable to the special jumper starting terminal of the vehicle.
2. Connect the clamp on the other end of the positive cable to the positive (+) terminal of another vehicle.
3. Connect the negative cable clamp to the negative battery terminal of another vehicle.
4. As shown, connect the clamp on the other end of the negative cable to a separate clamp.
5. Place jumper cable terminals firmly on, unpainted metal.



BATTERY INSTALLATION

NOTICE

To reduce the chance of sparks: Whenever the battery is removed, disconnect the black (negative) cable first. When reinstalling the battery, finally install the black (negative) cable.

1. Clean battery cables and terminals with a hard wire brush. Corrosion can be removed with a solution of 1 cup water and 1 tablespoon baking soda. Rinse well and dry thoroughly.
2. Put the battery in the tray.
3. Connect and tighten the red (positive) cable.
4. Connect and tighten the black (negative) cable.
5. Install a clear battery vent from the vehicle to the battery vent. (For conventional batteries only).
6. Install the battery press plate.
7. Tighten the battery clamp bolt.
8. Verify that cables are properly wired.

FUSE

All circuits on the ATV have fuses to protect electrical equipment from damage caused by high current (short circuit or overload).

If any of the electrical parts do not work, the fuse may have blown. If this happens, check and replace the fuse if necessary. You can consider electrical faults. First check whether the fuse needs to be replaced. If it is found to have blown, replace the blown fuse. There is a spare fuse in the fuse box. Check all fuses for other possible causes. Replace all blown fuses and check the working condition of components. All fuses are found in the fuse box. In the event of a system failure, see "Fuse Distribution and Ampere rating" for details of which fuses to check.

NOTICE

- **Do not use a fuse above the rated ampere value or replace it with anything else.**
- **Please use the same product. Never use wires for fuses, Even temporary replacements are not allowed.**
- **Do not modify fuses or fuse boxes.**


FUSE BOX


The fuse box is located under the vehicle's front access cover.

Remove the front shelf, and then take off the maintenance cover, you can see the fuse box at the bottom, move the buckles on the left and right sides of the fuse box cover to the outside, release the buckles, and open the fuse box.


NOTICE

The cover of the fuse box has a limited card slot, please pay attention to the installation direction when installing.






Normal fuse



Blow fuse

FUSE/RELAY DISTRIBUTION AND RATED AMPERAGE

There is a fuse distribution label on the top of the fuse box cover. You can refer to the fuse power on the label to find a fuse of the same power for replacement.



Rated amperage of fuse/relay and distribution

No.	Fuse/Relay	Power	No.	Fuse/Relay	Power
F3	IGNITION LOCK	15A	R1	REMOTE POWER-ON RELAY	12V 20A
F4	HEAD LIGHTS	20A	R2	AUXILIARY STARTER RELAY	12V 20A
F5	DASHBOARD/ ECU/OBD/TBOX	15A	R3	IG1 RELAY	12V 20A
F6	FUEL PUMP	15A	R4	MAIN RELAY	12V 20A
F13	12V-IG	15A	R6	DAYTIME RUNNING LIGHT RELAY	12V 20A
F14	LIGHT/RAKE/2-4 DRIVE SWITCH	15A	R7	FUEL PUMP RELAY	12V 20A
F15	ECU-IG	5A	R8	FAN RELAY	12V 20A
F16	ON-METER/BOX/ VEHICLE SPEED	10A	R10	HIGH LIGHT RELAY	12V 20A
F17	EPS-IG	5A	R11	LOW LIGHT RELAY	12V 20A
F18	POSITION LIGHT	7.5A	R12	BRAKE LAMP T RELAY	12V 20A
F20	MAIN FUSE	50A	R14	2WD 4WD RELAY	12V 20A
F23	ECU FUSE	15A	R15	4WD LOCK RELAY	12V 20A
F24	EPS FUSE	40A			
F31	FAN	20A			

NOTICE

Due to the continuous upgrading of products, the fuse may have slight changes. All functional positions and specifications in the fuse box are subject to the actual product.


FUSE BOX REPLACEMENT

To prevent an accidental short circuit, turn the ignition switch to the (OFF) position and check or replace the fuse.

To check or replace the circuit fuse, pull out the old fuse with a puller.

The fuse box cover is equipped with a puller. Using this tool will help you take out the fuse.

The fuse box cover is fitted with a common fuse which can be replaced.



1 Puller

2 Spare fuse

NOTICE

If a replacement fuse suitable for the circuit rating is not available, install a lower rated fuse.

APPEARANCE CARE

VEHICLE WASHING

High pressure water can damage parts and remove paint and decals.

1. Cover or plug the exhaust outlet prior to washing your Vehicle.
2. Fill a bucket with water. Mix in a mild, neutral detergent, such as dish washing liquid or a product made especially for washing motorcycles or automobiles.
3. Wash your Vehicle with a sponge or soft towel. As you wash, check for heavy grime. If necessary, use a mild cleaner/degreaser to remove the grime.
4. After washing, rinse your Vehicle thoroughly with plenty of clean water to remove any residue. Detergent residue can corrode alloy parts.
5. Dry your Vehicle with a chamois or a soft towel. Leaving water on the surface to air dry can cause dulling and water spots. As you dry, inspect for chips and scratches.
6. As a precaution, ride your Vehicle at a slow speed and apply the brakes several times. This will help dry the brakes and restore normal braking performance.

CLEANING TIPS

Avoid using automotive products, some of which may scratch your vehicle. Clean and polish regularly with a clean cloth and mat. Old or reused cloth and mats can contain dirt particles that can scratch the finish.

VEHICLE STORAGE

When the vehicle is not used for a long time, it should be appropriately stored. The vehicle should be parked and cleaned. If there is no indoor storage, covered outdoor storage is recommended.

TRANSPORTING THE ATV

Follow these procedures when transporting the vehicle.

1. Stop the engine.
2. Place the transmission in PARK.
3. Lock the parking brake.
4. Secure the fuel cap, oil cap and seats.
5. Always tie the frame of the ATV to the transporting unit securely with suitable straps or rope. Do not attach tie straps to the front A- arm bolt pockets, racks or handlebars.
6. Remove the key to prevent loss during transporting.



SPECIFICATIONS

TECHNICAL PARAMETERS OF VEHICLE.....	145
VEHICLE IDENTIFICATION NUMBER	149
THE FRAME NAMEPLATE	150

TECHNICAL PARAMETERS OF VEHICLE

Item	Model	
	SGWF500F-A7	SGWF500F-A8
Length	2075mm	2215mm
Width	1180mm	1180mm
Height	1230mm	1350mm
Wheel base	1300mm	1450mm
Ground clearance	250mm	
Turning diameter	5900 mm	6400mm
Curb weight	370kg	385kg
Front rack load	40kg(88 lb)	
Rear rack load	60kg(132 lb)	
Recommended Traction quality Pulled load quality)	150kg(331 lb)	
Engine model	193MR	
Engine type	Four stroke, single cylinder, water cooled, vertical, double overhead camshaft	
Cylinder diameter × stroke	93 × 73.6 mm	
Engine displacement	499cm ³	
Compression ratio	(10.7 ± 0.5): 1	
Idle speed	1350 ± 100 r/min	
Maximum power	26kW / 7250 r/min	
Maximum torque	37.5 N·m / 5750 r/min	

Item	Model	
	SGWF500F-A7	SGWF500F-A8
Starting way	Electric start	
Lubrication way	Pressure spray	
Engine oil type	SAE 10W-40 SJ or higher	
Engine oil capacity	2.2 L	
Front axle gear oil type	SAE 80W-90 GL-5	
Empty Volume	170 ml	
Rear axle gear oil model	SAE 80W-90 GL-5	
Empty Volume	260 ml	
Air filter	Paper filter element	
Fuel tank type	Barrier type plastic fuel tank	
Fuel tank capacity	18 L	
Fuel type	Petrol or E5	
Throttle type	JZD42B-1	
Spark plug type	CPR7EA / B7RTC	
Spark plug clearance	0.6~0.8mm	
Variable speed way	CVT	
Shift sequence	L-H-N-R-P	
Variable speed ratio	0.6-2.967	
L Transmission ratio	11.8-58.3	
H Transmission ratio	6.8-33.6	
Reverse gear ratio	9.7-48	


Item	Model	
	SGWF500F-A7	SGWF500F-A8
Tire type	Vacuum tire	
Front tire specification	24x8.00-12/25x8.00-12	
Rear tire specification	24x10.00-12/25x10.00-12	
Front tire pressure	7.0psi (48.3kPa)	
Rear tire pressure	7.0psi (48.3kPa)	
Brake type	front double disc brake, rear single disc brake (Brake shaft)/front double disc brake、 rear double brake	
Foot brake mode	Right foot operation	
Front braking mode	Right operation	
Brake fluid type	DOT4	
Front suspension	Front double A rocker arm	
Rear suspension	Rear double A rocker arm	
Front shock absorber	Spring + oil resistance Spring + air resistance	
Rear shock absorber	Spring + oil resistance Spring + air resistance	
Front wheel travel	200mm	
Rear wheel travel	200mm	
Ignition mode	electricity (ECU)	
Charge	450W / 5500 rpm	
Battery	12V 32Ah	

Item	Model	
	SGWF500F-A7	SGWF500F-A8
headlamp	Low light Power 9.5(W)	
	High beam power 17(W) 32000cd	
	Day Light 20(W)	
	Turn signal 10 (W)	
	Front Position Light 2.7(W)	
Rear tail light - position light	2.1 (W)×1	
Rear taillights - Brake lights	4.7 (W)×1	
Turn signal lamp	2.4 (W)×2	


VEHICLE IDENTIFICATION NUMBER

Record the frame identification code and engine serial code in the spaces provided for assistance when ordering spare parts from a dealer or for reference in case the vehicle is stolen.

The frame identification number is located on the frame cross under the seat cushion pipe under the seat cushion.



Frame identification number




Engine serial number

Frame identification code

Engine serial code

THE FRAME NAMEPLATE

The frame nameplate is located on the right rear wheel frame of the vehicle and displays basic feature information, including the VIN code. The VIN code is required when the vehicle is activated for the first time.





TROUBLESHOOTING

DRIVE BELT AND COVER PROBLEMS	152
ENGINE DOESN'T TURN OVER	154
ENGINE PINGS OR KNOCKS	154
ENGINE STOPS OR LOSES POWER	155
ENGINE TURNS OVER, FAILS TO START	155
ENGINE BACKFIRES.....	156
ENGINE RUNS IRREGULARLY, STALLS OR MISFIRES	156
ENGINE RUNS IRREGULARLY, STALLS OR MISFIRES	157
ENGINE STOPS OR LOSES POWER	158
DIAGNOSTIC DISPLAYS CODE DEFINITIONS.....	159

With all the challenges you can encounter on-road, there's chance that sometime something may go wrong. This section gives practical advice to help you deal with a wide range of problems. Take time to read this section before you ride.

DRIVE BELT AND COVER PROBLEMS

Possible Cause	Solution
Driving the ATV onto a pickup or tall trailer in high range	Shift transmission to low range during loading of the ATV to prevent belt burning.
Starting out going up a steep incline	When starting out on an incline, use low range or dismount the ATV (after first applying the park brake) and perform the K-turn as described on page 65.
Driving at low RPM or low ground speed (at approx. 3-6 MPH (5-10 km/h))	Drive at a higher speed or use low range more frequently. The use of low range is highly recommended for cooler CVT operating temperatures and longer component life.
Insufficient warm-up of ATVs exposed to low ambient temperatures	Warm the engine before driving. The belt will become more flexible and prevent belt burning.
Slow and easy clutch engagement	Use the throttle quickly and effectively for efficient Engagement.
Towing/pushing at low RPM/low ground speed	Use low range only.
Utility use/plowing snow, dirt, etc	Use low range only.

Possible Cause	Solution
Stuck in mud or snow	Shift the transmission to low range, and carefully use fast, aggressive throttle application to engage clutch. WARNING: Excessive throttle may cause loss of control and vehicle overturn.
Climbing over large objects from a stopped position	Shift the transmission to low range, and carefully use fast, brief, aggressive throttle application to engage clutch. Excessive throttle may cause loss of control and vehicle overturn.
Belt slippage from water or snow ingestion into the CVT system	Remove the CVT cover and drain the water from CVT.
Clutch malfunction	Contact your dealer for inspection of clutch components.

ENGINE DOESN'T TURN OVER

Possible Cause	Solution
Poor engine performance	Check for fouled plugs or foreign material in gas tank, fuel lines, or throttle. Contact your dealer for service.
Tripped circuit breaker	Reset the breaker.
Low battery voltage	Recharge battery to 12.5 VDC.
Loose battery connections	Check all connections and tighten
Loose solenoid connections	Check all connections and tighten

ENGINE PINGS OR KNOCKS

Possible Cause	Solution
Poor quality or low octane fuel	Replace with recommended fuel
Incorrect ignition timing	See your dealer
Correct spark plug gap or heat range	Set gap to specs or replace plugs

ENGINE STOPS OR LOSES POWER

Possible Cause	Solution
Overheated engine	Clean radiator screen and core if equipped Clean engine exterior See your dealer

ENGINE TURNS OVER, FAILS TO START

Possible Cause	Solution
Out of Fuel	Refuel
Clogged fuel valve or filter	Inspect and clean or replace
Water is present in fuel	Drain the fuel system and refuel
Fuel valve is out of use	Replace
Old or non-recommended fuel	Replace with new fuel
Fouled or defective spark plug(s)	Inspect plug(s), replace if necessary
No spark to spark plug	Inspect plug(s), verify stop switch is on
Crankcase filled with water or fuel	Immediately see your dealer
Overuse of choke	Inspect, clean and/or replace spark plugs
Clogged fuel injector	Clean or replace new fuel injector
Low battery voltage	Recharge battery to 12.5 VDC
Mechanical failure	See your dealer

ENGINE BACKFIRES

Possible Cause	Solution
Weak spark from spark plugs	Inspect, clean and/or replace spark plugs
Incorrect spark plug gap or heat range	Set gap to specs or replace plugs
Old or non-recommended fuel	Replace with new fuel
Incorrectly installed spark plug wires	See your dealer
Incorrect ignition timing	See your dealer
Mechanical failure	See your dealer

ENGINE RUNS IRREGULARLY, STALLS OR MISFIRES

Possible Cause	Solution
Fouled or defective spark plugs	Inspect, clean and/or replace spark plugs
Worn or defective spark plug wires	See your dealer
Incorrect spark plug gap or heat range	Set gap to specs or replace plugs
Loose ignition connections	Check all connections and tighten
Water present in fuel	Replace with new fuel
Low battery voltage	Recharge battery to 12.5 VDC

ENGINE RUNS IRREGULARLY, STALLS OR MISFIRES

Possible Cause	Solution
Kinked or plugged fuel vent line	Inspect and replace
Incorrect fuel	Replace with recommended fuel
Clogged air filter	Inspect and clean or replace
Reverse speed limiter malfunction	See your dealer
Electronic throttle control malfunction	See your dealer
Other mechanical failure	See your dealer
Possible Lean or Rich Fuel Mixture Cause	Solution
Low or contaminated fuel	Add or change fuel and clean the fuel system
Low octane fuel	Replace with recommended fuel
Clogged fuel filter	See your dealer
Incorrect jetting	See your dealer
Overuse of choke	Inspect, clean and/or replace spark plugs
Fuel is very high octane	Replace with lower octane fuel

ENGINE STOPS OR LOSES POWER

Possible Cause	Solution
Out of fuel	Refuel
Kinked or plugged fuel vent line	Inspect and replace
Water present in fuel	Replace with new fuel
Overuse of choke	Inspect, clean and/or replace spark plugs
Fouled or defective spark plugs	Inspect, clean and/or replace spark plugs
Worn or defective spark plug wires	See your dealer
Incorrect spark plug gap or heat range	Set gap to specs or replace plugs
Loose ignition connections	Check all connections and tighten
Low battery voltage	Recharge battery to 12.5 VDC
Clogged air filter	Inspect and clean or replace
Reverse speed limiter malfunction	See your dealer
Electronic throttle control malfunction	See your dealer
Other mechanical failure	See your dealer

DIAGNOSTIC DISPLAYS CODE DEFINITIONS

System	Failure Code	Failure Description
ECU	P0262	Cylinder 1 Injector Circuit High
	P0261	Cylinder 1 Injector Circuit Low
	P0201	Injector Circuit/Open – Cylinder 1
	P0629	Fuel Pump “A” Control Circuit High
	P0628	Fuel Pump “A” Control Circuit Low
	P0627	Fuel Pump “A” Control Circuit /Open
	P0511	Stepper motor open circuit or unreasonable
	P0509	Stepper motor short circuit to 12V power supply
	P0508	Stepper motor short circuit to ground
	P2300	Ignition coil short circuit to ground fault
	P0108	Manifold Absolute Pressure/ Barometric Pressure Circuit High
	P0107	Manifold Absolute Pressure/ Barometric Pressure Circuit Low
	P0322	Ign./Distributor Eng.Speed Inp.Circ. No Signal
	P0113	Intake Air Temperature Sensor 1 Circuit Low
	P0112	Intake Air Temperature Sensor 1 Circuit High
	P0118	Engine Coolant Temperature Sensor 1 Circuit Low
	P0117	Engine Coolant Temperature Sensor 1 Circuit High
	P0563	System Voltage High
	P0562	System Voltage Low
	P0560	System Voltage Not plausible

ECU	P0501	Vehicle Speed Sensor "A" Range/Performance
	P0123	Throttle position sensor High Voltage
	P0122	Throttle position sensor Low Voltage
	P0032	O2 Sensor Heater Control Circuit High Bank 1 Sensor 1
	P0031	O2 Sensor Heater Control Circuit Low Bank 1 Sensor 1
	P0030	O2 Sensor Heater Control Circuit Bank 1 Sensor 1
	P0132	O2 Sensor Circuit High Voltage Bank 1 Sensor 1
	P0131	O2 Sensor Circuit Low Voltage Bank 1 Sensor 1
	P0130	O2 Sensor Circuit No Activity Detected Bank 1 Sensor 1
	P0134	O2 Sensor Circuit Bank 1 Sensor 1
	P0692	Fan 1 Control Circuit High
	P0691	Fan 1 Control Circuit Low
	P0480	Fan 1 Control Circuit
	P0459	Evaporative Emission System Purge Control Valve Circuit High
	P0458	Evaporative Emission System Purge Control Valve Circuit Low
P0444	Evaporative Emission System Purge Control Valve Circuit Open	
EPS	E0001	No midpoint of torque is written
	E0002	No end point of rotor angle is written
	E0003	Memory read write failure
	E0004	The main torque sensor is disconnected
	E0005	Abnormal output of main torque sensor
	E0006	The secondary torque sensor is disconnected

EPS	E0007	Abnormal output of secondary torque sensor	
	E0008	The difference between main and secondary torques is too large	
	E0009	The difference between the main torque before and after amplification is too large	
	E0010	Electrical machinery unassisted	
	E0011	Over electric current	
	E0012	Abnormal busbar electric current	
	E0013	CAN communication abnormal (Output abnormally)	
	E0014	Rotor Angle jump	
	E0015	The rotor Angle sensor is disconnected	
	E0016	Power module failure	
	E0017	Abnormal A phase electric current	
	E0018	Abnormal C phase electric current	
	E0019	Steering wheel Angle small gear abnormal	
	E0020	Steering wheel Angle middle gear abnormal	
	E0021	Steering wheel Angle jumps	
	E0022	Steering wheel Angle value exceeds limit	
	E0023	The steering wheel Angle is not right	
	E0024	Abnormal voltage at electrical machinery end	
	T-BOX	T0001	GPS module failure
		T0002	4G module failure
T0003		Bluetooth module failure	
T0004		Sensor failure	
T0005		Power CAN failure	
T0006		Body CAN failure	



EMISSION CONTROL SYSTEM

SOURCE OF EXHAUST EMISSIONS	163
EXHAUST EMISSION CONTROL SYSTEM.....	163
CRANKCASE EMISSION CONTROL SYSTEM	163
NOISE CONTROL SYSTEM.....	163

SOURCE OF EXHAUST EMISSIONS

The combustion process produces carbon monoxide(CO), oxides of nitrogen(NO_x)and hydrocarbons(HC). Control of hydrocarbons and oxides of nitrogen is very important because, under certain conditions, they react to form photochemical smog when subjected to sunlight. Carbon monoxide does not react in the same way, but it is toxic.

EXHAUST EMISSION CONTROL SYSTEM

The exhaust emission control system includes a PGM-F system and oxygen sensor.

No adjustments to this system should be made although periodic inspection of the components is recommended.

The exhaust emission control system is separate from the crankcase emission control system.

CRANKCASE EMISSION CONTROL SYSTEM

The engine is equipped with a closed crankcase system to prevent discharging crankcase emissions into the atmosphere. Blow-by gas is returned to the combustion chamber through the air cleaner.

NOISE CONTROL SYSTEM

Do not modify the engine,air intake or exhaust components, in order to meet local noise level requirements.



WARRANTY

LIMITED WARRANTY	165
REGISTRATION.....	165
EXCLUSIONS-ARE NOT WARRANTED	165
LIMITATIONS OF WARRANTIES AND REMEDIES.....	166
MAINTENANCE LOG	169

LIMITED WARRANTY

SEGWAY TECHNOLOGY CO., LTD gives a LIMITED WARRANTY on components of your new SEGWAY vehicle against defects in parts or workmanship when properly set up and operated in accordance with the recommendations set forth in the SEGWAY Owner's Manual. SEGWAY gives a TWO (2) YEAR limited warranty for use of the vehicle. For commercial use, SEGWAY gives a SIX (6) MONTHS limited warranty. This warranty covers parts and labor charges for repair or replacement of defective parts and begins on the date of purchase by the original retail purchaser.

This warranty is transferable to another owner during the warranty period through a SEGWAY dealer, but any such transfer will not extend the original term of the warranty. The duration of this warranty may vary by international region based upon local laws and regulations.

REGISTRATION

At the time of sale, the Warranty Registration Form must be completed by your dealer and submitted to SEGWAY within ten days of purchase. Upon receipt of this registration, SEGWAY will record the registration for warranty.

EXCLUSIONS-ARE NOT WARRANTED

The following are not warranted under any circumstances:

1. Normal wear and tear.
2. Routine maintenance items, tune-ups, adjustments.
3. Damage caused by failure to provide proper maintenance and/or storage, as described in the Owner's Manual.

4. Damage resulting from removal of parts, improper repairs, service, maintenance, or use of parts not manufactured or approved by SEGWAY or resulting from repairs done by a person that is not an authorized servicing SEGWAY dealer.
5. Damage caused by abuse, abnormal use, neglect or operation of the product in a manner inconsistent with the recommended operation described in the Owner's Manual.
6. Damage resulting from accident, submersion, fire, theft, vandalism or any force majeure.
7. Operation with fuels, oils or lubricants which are not suitable for use with the product. (see the section " Technical parameters of vehicle "on Owner's Manual).
8. Damages from rust, corrosion resulted from salty water or corrosive material.
9. Damage resulting from the racing or any other competitive activity.
10. Damage resulting from the vehicle has been altered or modified in such a way so as to adversely affect its operation, performance or durability, or has been altered or modified to change its intended use.

LIMITATIONS OF WARRANTIES AND REMEDIES

This limited warranty excludes any failures that are not caused by a defect in material or workmanship. This warranty provides no coverage for consumable components, general wear items, or any parts exposed to friction surfaces, stresses, environmental conditions and/or contamination for which they were not designed or not intended, including but not limited to the following items:

- Batteries
- Bearings
- Brake components
- Bushings
- Throttle body components
- Circuit breakers/fuses
- Clutches components
- Coolants
- Drive belts
- Electronic components
- Engine components
- Filters
- Finished/unfinished surfaces
- Hydraulic components/fluids
- Light bulbs/lamps
- Lubricants
- Sealants
- Seat components
- Spark plugs
- Steering components
- Suspension components
- Wheels and tires

This warranty provides no coverage for personal loss or expense, including mileage, transportation costs, hotels, meals, shipping or handling fees, product pick-up or delivery, replacement rentals, loss of product use, loss of profits, or loss of vacation or personal time.

THE EXCLUSIVE REMEDY FOR BREACH OF THIS WARRANTY SHALL BE, AT SEGWAY' OPTION, REPAIR OR REPLACEMENT OF ANY DEFECTIVE MATERIALS, COMPONENTS, OR PRODUCTS. THE REMEDIES SET FORTH IN THIS WARRANTY ARE THE ONLY REMEDIES AVAILABLE TO ANY PERSON FOR BREACH OF THIS WARRANTY. SEGWAY SHALL HAVE NO LIABILITY TO ANY PERSON FOR INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES OF ANY DESCRIPTION, WHETHER ARISING OUT OF EXPRESS OR IMPLIED WARRANTY OR ANY OTHER CONTRACT, NEGLIGENCE, OR OTHER TORT OR OTHERWISE. THIS EXCLUSION OF CONSEQUENTIAL, INCIDENTAL, AND SPECIAL DAMAGES IS INDEPENDENT FROM AND SHALL SURVIVE ANY FINDING THAT THE EXCLUSIVE REMEDY FAILED

OF ITS ESSENTIAL PURPOSE.THE IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE IS EXCLUDED FROM THIS LIMITED WARRANTY. ALL OTHER IMPLIED WARRANTIES (INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTY OF MERCHANTABILITY) ARE LIMITED IN DURATION TO THE ABOVE SIX MONTH WARRANTY PERIOD.SEGWAY DISCLAIMS ALL EXPRESS WARRANTIES NOT STATED IN THIS WARRANTY. SOME STATES DO NOT PERMIT THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES OR ALLOW LIMITATIONS ON THE DURATION OF IMPLIED WARRANTIES, SO THE ABOVE LIMITATIONS MAY NOT APPLY TO YOU IF INCONSISTENT WITH CONTROLLING REGION LAW.

MAINTENANCE LOG

Use the following chart to record periodic maintenance.

VIN	Date	Miles(Km)or Hours	Service item